HOLDEN

SHUTTLE



OWNER HANDBOOK

Vehicle Identification Certificate

Owner's Name.....

Address.....

Town.....State.....Postcode.....

Phone: Business.....Private.....

Reg. No.....Colour.....

Vehicle Model.....

V.I.N. (Vehicle Identification Number).....

Body No.....Engine No.....

Chassis No. for Service Identification—on G.V.M. Plate.....

Trans. No.....Trim No.....

Rear Axle: Ratio(s).....Type.....

MAXIMUM GROSS VEHICLE MASS

The maximum gross vehicle mass rating is stamped on the GVM plate attached to the body. Vehicles loaded within this rating and properly maintained will repay the owner in maximum performance with minimum operating costs.

Registered Tare Weight.....

G.V.M.R. (Gross Vehicle Mass Rating).....

Date of Acquisition.....

Odometer Reading.....

Selling Dealer's Stamp &

Signature.....

Part No. 92030968

FEB. 1986

Message from GMH

Thank you for choosing Holden. Your new Vehicle is the product of many years research and planning. We are very pleased and proud of the result—as we are sure you will be. To understand your new vehicle fully, please take the time to read through this handbook and keep it in the vehicle at all times for quick reference.

Full understanding of your vehicle's performance, warranty and maintenance procedures will add greatly to your enjoyment. On behalf of all here at GMH, may we wish you and your Vehicle many years of happy motoring.

This handbook contains important information necessary for the good performance and maintenance of the vehicle. Please leave it in the vehicle at the time of resale to assist the new owner.

See inside back cover for important information on what to do at the scene of an Accident.

New Vehicle Warranty

GENERAL MOTORS-HOLDEN'S SALES PTY. LTD.

(INCORPORATED IN VICTORIA)

GENERAL MOTORS-HOLDEN'S SALES PTY. LIMITED

(INCORPORATED IN VICTORIA)

New Vehicle Warranty

GENERAL MOTORS-HOLDEN'S SALES PTY. LTD. HEREBY WARRANTS THAT IT WILL MAKE GOOD, WITHOUT CHARGE, ANY DEFECT WHICH APPEARS IN THE VEHICLE IDENTIFIED IN THE VEHICLE IDENTIFICATION CERTIFICATE FOUND ON THE INSIDE OF THE FRONT COVER.

Provided

1. the defect has been notified to an authorised GMH Dealer or Service Dealer:
   (a) before the vehicle has travelled a distance of 20,000 km, or:
   (b) within 12 months of the date of delivery of the vehicle to the first retail purchaser (or in the case of a Demonstrator vehicle within 12 months of the date when it was first placed into service by the Dealer)

   whichever comes first, and

2. the vehicle has been returned to an authorised GMH Dealer or Service Dealer

And

3. the Dealer has determined that the defect complained of *is* one of material or workmanship and *is not* caused by:
   (a) misuse or abuse of the vehicle such as by racing, rallying, overloading, etc. or by neglect
   (b) operation of the vehicle after it is known to be defective
   (c) accident or deliberate act
   (d) atmospheric fallout or flood, hail, salt, etc.
   (e) failure to carry out proper maintenance service
   (f) alteration or modification of the vehicle
   (g) the fitting of parts or accessories not marketed by GMH
   (h) any work carried out on the vehicle by someone other than an authorised GMH Dealer or Service Dealer,

BY THE DEALER (or as otherwise decided by GMH Sales) MAKING GOOD THE DEFECT BY REPAIR OR, AT THE OPTION OF GMH SALES, BY REPLACEMENT.

Excluded from this Warranty are

- defects in tyres or tubes (these being warranted by their manufacturers), and services such as engine tuning, brake adjustment, replacement of air and oil filters, etc. which are required as part of normal vehicle maintenance.

This Warranty applies only to vehicles operated in Australia and is given to the person who is entitled to possession of the vehicle whether as owner lessee or otherwise and is given in addition to all rights conferred by law on that person.

Owners of vehicles operated outside Australia should consult their local dealer regarding the warranty applicable to their vehicles.

Notice to Customers

No GMH dealer or other person is authorised or permitted to give or make any statement assertion or undertaking in relation to the quality performance characteristics descriptions or fitness for any purpose of any GMH product or in connection with the supply of any GMH product, which is at variance with any written statement assertion or undertaking on any of these subjects given or made by General Motors-Holden's Limited or General Motors-Holden's Sales Pty. Ltd. in its published sales literature, and neither company accepts any liability for any such unauthorised action.

General Motors-Holden's Limited and General Motors-Holden's Sales Pty Ltd have franchised dealers in many parts of Australia for the sale of service parts and the provision of service to owners of GMH's products. Every endeavour is made to ensure that such dealers carry adequate stocks of service parts, and are equipped to provide satisfactory service, but neither General Motors-Holden's Ltd. nor General Motors-Holden's Sales Pty. Ltd. makes any promise that such parts or service facilities will be available, or available at any specific location or any particular time.

GMH Parts and Accessories Warranty

General Motors-Holden's Limited warrants in respect of GMH parts and accessories required as replacement parts, that it will make good by repair or at its option by replacement any defect occurring in any such GMH parts and accessories within 3 months from the date of acquisition or in the case of a GMH part or accessory which has been installed in a vehicle by a GMH Dealer or Service Dealer before such vehicle has travelled a distance of 6,500 kms from the date of installation, whichever first occurs.

Table of Contents

Index Page 112

This handbook applies to the Holden Shuttle vehicles, and explains all equipment including options. Therefore you may find reference to some equipment not installed on your vehicle.

Section 1: Getting to know your Shuttle
Safety Checklist, Running In, Fuel Economy Tips, Safe, Driving Hints, Keys and Locks, Windows, Seat Belts, Seats, Mirrors.
Page 3.

Section 2: Starting and Operating
Controls and Instruments, Steering Column Controls, Transmission, Switches, Instruments and Lights, Floor Controls, Radio, Heating and Ventilation, Air Conditioning, Starting and Driving.
Page 17.

Section 3: Emergencies, Safety and Emission
Spare Wheel Storage, Wheel Changing, Emergency Starting, Towing, Overheating, Warning Lights, Emission Control System
Page 37.

Section 4: Customer Assistance and Authorised GMH Dealers
Customer Assistance, Authorised GMH Dealers.
Page 47.

Section 5: Specifications
Serial Numbers, Model Identification, Vehicle Dimensions, Engine Data, Capacities, Clearance and Settings, Fuses, Headlamps and Bulbs.
Page 57.

Section 6: Appearance, Maintenance and Service
Caring for your Vehicle, Washing Tips, Interior Cleaning, Service and Maintenance, Oil, Cooling System, Lubricants, Tyres, Owner's Responsibility, Maintenance Schedules, Service Operations, Labour Times.
Page 65.

HOLDEN GMH

When it comes to servicing, remember that a GMH Dealer has the trained personnel and specialised equipment to correctly service your vehicle.

For the proper maintenance and performance of the vehicle use only quality GM and AC Delco parts which are identified by one of these trademarks.

The use of parts, additives or treatments other than those marketed by GM or AC Delco may be detrimental to your vehicle and may void your New Vehicle Warranty.

All illustrations and specifications contained in this Handbook are based on the latest product information available at time of publication approval. The right is reserved to make changes at any time, without notice, in prices, colours, materials, equipment, specifications and models and to discontinue models. Check with your Holden Dealer for complete information.

Section 1: Getting to Know your Shuttle

Safety Checklist

Follow these simple steps before driving your new Shuttle. They will help make your motoring safer and more enjoyable.

Before getting in

Check that the windows, mirrors and lights are clean.

Check the tyre inflation.

If you intend to reverse, check that the area behind you is clear.

Before driving off

Be sure you understand your vehicle and know how to operate it safely.

Be sure that all doors are securely fastened.

Position your seat for comfortable driving.

Adjust both rear vision mirrors.

FASTEN SEAT BELTS.

Check that the warning indicators light up when you turn the key to start the engine.

Release the parking brake.

If you are reversing again check that the area behind you is clear.

Caution: Never leave loose articles inside the vehicle — they may become dangerous projectiles if you have a collision or stop suddenly.

Maintenance for safety

The following items require regular attention in the interests of safety. If anything goes wrong with any one of them, an authorised GMH Dealer will help you.

- BRAKES.
- HORN.
- ALL LIGHTS.
- REAR VISION MIRRORS.
- SEAT BELTS.
- GLASS AREAS.
- EXHAUST SYSTEM.
- WINDOWS.
- STEERING AND WHEEL ALIGNMENT.
- WINDSHIELD WIPERS AND WASHERS.
- TYRES.
- SUSPENSION.

Running In

These days, there's no need to follow a rigid running-in schedule. However, if you observe a few simple points during the first few hundred kilometres of driving, you will add to the vehicle's future performance and economy.

For the first 1000 kilometres, don't go over 100 km/h. Up to 1500 kilometres, avoid driving at any one speed—either slow or fast—for any length of time.

Include some higher speeds in your driving. This helps prolong the life of parts and helps with fuel and oil economy. But never drive at high speed until the engine is thoroughly warm.

Full throttle acceleration is not recommended before the vehicle has done 3000 kilometres.

For the first 500 kilometres, heavy braking should be avoided, except in the case of emergency since brake misuse during this period could impair future braking efficiency.

Also avoid heavy prolonged pulling in low gears for first 400 kilometres.

Maximum allowable speed in each gear in km/h during Running-In period.

1st	2nd	3rd	4th	5th
20	35	65	95	110

OVERLOADING

Overloading not only shortens the service life of your vehicle, but also creates serious potential safety hazards.

The weight of the payload must be limited within the GVM rating and distributed over the front and rear axles so as not to exceed the axle capacity.

Refer to the SPECIFICATIONS' SECTION for GVM and Axle capacity.



Fuel Economy Tips

How you drive, and where you drive have an effect on your fuel economy. The following pointers will help reduce your fuel bill.

Avoid:

Hard Acceleration.

Excess Loading Weight.

Stop-Start Driving. Plan your trips ahead.

Excessive Speed. You will save on your fuel bill by driving at 80 km/h instead of 110 km/h.

ENGINE IDLING:
If you have to wait for more than a few minutes, turning off the engine will conserve fuel.

HARD DRIVING IN BUILT UP AREAS:
Energy is wasted as heat when braking. Hard driving up to stopping points is wasting fuel, as energy in the form of fuel is needed to accelerate again.

AIR CONDITIONER OPERATION: (where fitted)
Don't use your air conditioner unnecessarily. By using correct vent settings acceptable body comfort can be obtained in cool and moderate temperature conditions at the same time achieving better engine performance and economy.

Check:

Air Cleaner Element. A dirty air cleaner element reduces engine efficiency. Replace it at the required intervals.

Engine Tuning. An out of tune engine cannot give good fuel economy.

Tyre Inflation. Under inflation wastes fuel.

Wheel Alignment. Incorrect alignment makes the front wheels drag and puts an extra load on your engine.

Safe Driving Hints

Important

These items are listed as a safety reminder to you. The appropriate section of this handbook should be referred to for a more detailed explanation.

Carbon Monoxide

Avoid inhaling exhaust gases because they contain carbon monoxide, which is colourless and odourless. Carbon monoxide is a dangerous gas that can cause unconsciousness and is potentially lethal.

Ensure that rear door is closed and that door opening seals are not damaged or displaced.

Seat Belts

Various road laws require the wearing of seat belts. It is important that the habit of using these should be developed by yourself and others in the vehicle. In the interest of safety seat belts should be checked regularly. Your Dealer will inspect and check the belts for you as part of the normal Maintenance Plan Service. Never attempt to modify or change the seat belt away from the original specification as this will affect the operation of the belts and reduce their effectiveness, in preventing injury, in an accident.

Anti-Theft Ignition Steering Lock

DO NOT turn the ignition switch away from the ON position while the vehicle is in motion as this renders ineffective any power assisted equipment fitted to your vehicle. Never turn the key to lock position while the vehicle is in motion **as this will lock the steering of the vehicle and render it inoperative.**

Brakes

Driving through water may affect performance. Applying the brakes lightly will indicate whether they have been affected. To dry them quickly, lightly apply the brakes while maintaining a slow forward speed with an assured clear distance ahead until brake performance returns to normal.

Brake pedal travel should not be obstructed by ill-fitting floor mats or other interfering material under the pedal.

Power Assisted Brake

Power assisted brakes which are fitted to your vehicle utilise vacuum from the engine when it is running. Do not let the vehicle run down steep grades without the engine running. **Never** coast with the engine switched off.

Tyre Traction

A decrease in driving, cornering, and braking traction occurs when water, snow, ice, gravel, or other material is on the road surface. Driving practices and vehicle speed should be adjusted to the road conditions.

Cooling System

If the cooling system is hot, the radiator cap must not be removed quickly — it should be rotated slowly to the first stop, which permits the pressure to release slowly through the overflow pipe. It is advisable to cover the cap, with an old rag or cloth to avoid possible scalding.

Loose Articles

Do not leave a loose load or articles inside the vehicle. Stow articles by tying down if necessary.

Petrol Fumes

Always stop the engine and do not smoke or allow open flames or sparks near the vehicle when refuelling. If petrol fumes are noticed while driving, the cause should be determined and corrected without delay.

Keys and Locks

Your vehicle is fitted with a locking system which provides security for all doors.

Keys

The code number of each key is stamped on the key. Record the key numbers and keep the numbers in a safe place such as your wallet. NOT IN THE VEHICLE.
In the event the original keys are lost, duplicates can be made by your dealer using the key code information.

Doors

Front door handle

The doors can be opened by pulling the outside door handle.

Doors can be locked by inserting the starter switch key in the door key lock and turning it.



Front door lock (Outside)

The doors can be locked from outside without using the key by setting the door lock knob on the inside of door and closing the door with the outside handle pulled outward.

Be careful not to lock your keys in the vehicle.

Front inside door handle

The doors can be opened by pulling the inside door handle.

Front inside door lock

The doors can be locked by setting the door knob after closing the door.



Before driving, be sure that the doors are closed and locked, especially when small children are in the vehicle.

Sliding door handle outside

The door can be opened from outside by pulling the handle.

Sliding door lock (Outside)

The door lock on the sliding door can be locked or unlocked by turning the key.

Sliding door handle inside

The door can be opened from inside by pulling the handle.



Sliding door lock (Inside)

The door can be locked by setting the door knob before or after closing the door. *Before driving, be sure that the door is closed and locked, especially when small children are in the vehicle.*

Back door

The back door can be locked or unlocked by turning the key. The back door can be opened by pulling either handle at the right or left hand side. To close, lower it carefully.

A Hint

Door locks may ice up in cold weather. If this happens, warm the key before you insert it. You may have to do this several times.

Fuel tank filler cap

The vehicle is equipped with lockable fuel filler door which can be unlocked with starter key.

After refuelling, check to be sure the fuel filler door is locked up properly.







Windows

Regulator handle

Turn the window regulator handle to raise or lower the door windows on the front doors.

Rear Side Window (where fitted)

Slide open the windows with the window lock depressed. The windows are automatically locked when completely closed.

Ash tray

To use, pull out the tray. To clean, remove the tray by pulling it while depressing the centre flap.







Seat Belts

Study this section carefully. It is important that you understand how to correctly wear a seat belt. You should also ensure that all occupants wear a properly adjusted seat belt whenever the vehicle is moving.

Care of Seat Belts

Keep the belts clean and dry. Clean with a mild soap solution and lukewarm water. Keep sharp edges and damaging objects away from the belts.

Periodically, inspect the belts, buckles and anchorage points. Damage or fraying that could lessen the effectiveness of the system should be eliminated by replacing the belt assemblies. Do not bleach or dye the belts since this can cause severe loss of strength as also will cause contamination of the webbing with polishes, oils or chemicals—particularly battery acid.

Using Seat Belts

Various road laws require the wearing of seat belts. It is important that the habit of using these should be developed by yourself and others using the vehicle.

The adjustment and operating instructions are detailed in this Section together with the Seat Adjustment; it being important that both positions be comfortable in order that the driver may devote his entire attention to the job of driving and observing the road.

Your GMH Dealer will be pleased to advise you about the various types of child restraints available.

Children should be belted in at all times.

Never use a child restraint as an adult seat belt—it will not take the extra weight.

Releasing Belts

To release the belts: press the release button and allow the belt to retract. Check that it fully retracts without twisting or turning.

Safety Hints

Check seat belts regularly. Your GMH Dealer will do this as part of normal Guardian Maintenance.

Adjust seat belts firmly. A loose belt is no help at all. Seat belts must be replaced if they have been in use during a severe impact — even if there's no obvious damage.

Don't wear a belt with twisted straps.

Don't ever put a seat belt around a child being nursed on the lap.

IMPORTANT: Don't use belts that are twisted—untwist them before making any adjustments and be sure that they contour around the body comfortably when adjustments are complete.

Lap/Sash Combination Belt

Emergency Locking Retractor Type

A firm, low position across the pelvis by the lap section of the Lap/Sash



Combination Belt is essential in order that the force exerted by the Lap Belt in a collision may be spread over the strong hip bone structure and not across the soft abdominal area.

This type of seat belt allows the wearer to move bodily while the seat belt is fastened. It is also dual sensitive.

The first way the locking mechanism is activated is by sudden changes of vehicle speed or vehicle direction, as in the case of firm brake application or vehicle impact during an accident.

This phase of the retractor mechanism's operation can be tested by allowing the body to be restrained only by the belt during firm application of the vehicle brakes, at between 2-5 km/h (brisk walking speed) under safe conditions.

The belt should lock immediately, stopping all belt movement. The second way the locking mechanism is activated is by a sudden extension of the belt from the retractor housing. This phase of the retractor mechanism's operation can be tested by holding the belt tightly and giving it a sudden firm jerk. The retractor mechanism should lock immediately, stopping all belt movement.
These checks should be carried out regularly.

WARNING: No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.

TONGUE RESTRICTOR

This belt system incorporates a tongue restrictor which can be moved along the belt to locate and hold the tongue in any desired position.
WARNING:The positioning of the tongue restrictor must never interfere with or stop the belt from fully retracting.

BELT ADJUSTMENT

1. Adopt a satisfactory seating position.
2. Bring the metal tongue across the body and snap home the Tongue into the Buckle.
3. After fastening, settle the belt by running a hand under the belt, starting at the outer hip area, then across to the tongue and up the sash section. This will feed back unwanted belt length to the retractor.
4. Finally check the fit and adjustment.

Lap Type Belts

BELT ADJUSTMENT

1. Adopt a satisfactory seating position.
2. Bring the Tongue Adjuster across the body and snap home the Tongue into the Buckle.
3. Adjust the belt to obtain a firm fit. A firm fit low position across the pelvis is essential in order that the force exerted by the lap belt in a collision may be spread over the strong hip bone structure and not across the soft abdominal areas.

   To Lengthen—Tilt the Tongue Adjuster and pull the belt to the right of the finger grip bar.



To Shorten—Tilt the Tongue Adjuster and use the serrated Finger Grip Bar to pull the belt through the Tongue Adjuster.

BELT STOWAGE

When not in use these belts should be kept with the tongue latched into the appropriate buckle.

INFANTS UNABLE TO SIT BY THEMSELVES should be carried in a padded, covered bassinet placed **across** the back seat. A suitable type of bassinet restraining system should be used.

CHILDREN ABLE TO SIT UP should be restrained with the regular seat belt or an approved child restraint. In some states it is Law that children must be belted in, whenever they are travelling in a vehicle in which seat belts are installed. CHILDREN SHOULD BE RESTRAINED AT ALL TIMES WHEN RIDING IN A MOTOR VEHICLE.

Where children are carried without a child restraint and the seating position of the child is to be raised this is to be done only by means of a support which is retained by the seat belt.

ON NO ACCOUNT SHOULD A LOOSE CUSHION BE USED, THIS COULD RESULT IN SERIOUS INJURY IN THE CASE OF VEHICLE COLLISION.

CHILD RESTRAINT ANCHORAGES

Wagon models are desgined to accommodate a child restraint on the rear seat. When using a child restraint, carefully read and follow the Installation Instructions attached to it.

Anchorages are located on the rear roof beam, behind the third row seats.



Remove the plugs and install child restraints with the correct anchor bolts.

Only approved child restraint harnesses should be used on anchorage points. See your GM-H Dealer for advice about the various types of approved child restraints available.

WARNING:
Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts or harnesses.

The GM Child Love Seat is designed for children weighing 9 to 19 kg, up to 1 metre in height, who are able to sit up alone.

AUSTRALIAN DESIGN RULES: WARNINGS

Seat belts are designed to bear upon the bony structure of the body, and should be worn low across the front of the pelvis, or the pelvis, chest and shoulders, as applicable; wearing the lap section of the belt across the abdominal area must be avoided.

Seat belts should be adjusted as firmly as possible, consistent with comfort, to provide the protection for which they have been designed. A slack belt will greatly reduce the protection afforded to the wearer.

Care should be taken to avoid contamination of the webbing with polishes, oils and chemicals, and particularly battery acid. Cleaning may safely be carried out using mild soap and water. The belt should be replaced if webbing becomes frayed, contaminated or damaged.

It is essential to replace the entire assembly after it has been worn in a severe impact even if damage to the assembly is not obvious.

Belts should not be worn with straps twisted.

Each seat belt assembly must only be used by one occupant; it is dangerous to put a belt around a child being carried on the occupant's lap.

No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.

The positioning of the tongue restrictor must never interfere with or stop the belt from fully retracting.

Rear Vision Mirrors

Inside rearview mirror

To adjust, push the mirror right or left, and up or down.

Anti-Glare Type (where fitted)

Where the anti-glare mirror is fitted, a control lever on the lower edge of the mirror enables an anti-glare reflector to be used during night driving. This reduces headlamp glare from following vehicles.

During normal daylight operation, the lever should be set forward. To reduce glare at night, move the lever backwards.

Outside rearview mirror

Adjust the outside rearview mirror so you can just see the side of your vehicle in the side of the mirror closest to the vehicle. This helps you determine your relation to objects seen in the mirror. When selecting the most suitable angle for the mirror, ensure that the driver's head is in the normal position for driving then adjust the mirror angle to suit.

Engine compartment cover

WAGON: The engine compartment cover is located between the two front seats. To gain access to the engine, first remove the middle section of the rear tray. Release the lock lever (under the carpet) and lift the console section between the two front seats forward. Ensure the support stay is in the forward position.

PANEL VAN & WINDOW VAN: To gain access to the engine, move the middle seat back forward, using the lever located at the side of the seat back. The lock lever for the cover will then be found under the carpet or mat.







Seats

Driver's Seat

Seat adjuster:

The driver's seat can be moved forward or rearward for most comfortable position.

Push sideways on the lever, located at the front lower part of the seat, to release the seat adjuster lock so that the seat can be moved forward or rearward as desired. After adjusting the seat position, move the seat forward and backward to be sure the seat adjusters have been latched. **Do not adjust the seat whilst the vehicle is moving.**



Seats (Wagon Models)

Seat Backs

Seat back inclination can be adjusted by use of release levers located on body side end of seats.



Access to Third Row Seat

Access to third row seat is achieved by the release of the second row left hand seat and hinging seat assembly forward. Release is achieved by moving release lever forward.

Folding Rear (Third) Seat for extra Luggage Space

Move the lever at the left side of the seat rearward and fold the seat back fully forward to lay on the seat. Release the lever under the rear of the seat and fold the seat (with the folded seat back) forward to an upright position. Set the two retaining levers at both sides of the seat into the fittings provided.

To reset the seat, reverse the above operation, making sure you place the seat belts in their normal position.

Sleeping Facility

Both second and third row seat backs can be fully reclined to form a flat bed.







Section 2: Starting and Operating

EXHAUST GAS WARNING
Carbon Monoxide Poisoning

Exhaust gases contain carbon monoxide which can cause unconsciousness and even death.

Long term exposure to low levels of carbon monoxide can lead to permanent damage of the body.

You could breathe the gases in if the exhaust system on your vehicle is faulty.

Have the vehicle checked thoroughly each time it is serviced. If you notice a change in exhaust noise, or if the back of your vehicle is damaged, take it to your GMH dealer for inspection.

If you must drive with a faulty exhaust, drive with all the windows open.

Danger

Don't ever sit in a parked vehicle with the engine running for any length of time. And don't leave the kids in there either.

Don't run the engine in the garage any more than necessary to move the vehicle.

Don't ever travel with the rear door open as this allows dangerous carbon monoxide gas to be drawn into the vehicle. This is most harmful and can be fatal to humans and also to animals.

Exhaust Pollution

Your Shuttle is equipped with several features designed to minimise exhaust pollution.

CONTROLS AND INSTRUMENTS



1 AM radio (van models)
2* Electric digital clock
3 Centre ventilation grille
4 Heater control panel
5* Rear heater switch
6 Rear washer switch
7 Rear wiper switch
8 Transmission gear shift lever (van models)
9 Meter and indicator lights
10 Steering wheel
11 Indicator lights
12 Rear defogger switch
13 Side ventilator grille
14 Combination lights switch
15 Hazard warning flasher switch
16 Accelerator pedal
17 Windshield wiper and washer control lever
18 Clutch pedal
19 Parking brake lever
20 Cigarette lighter
21 AM/FM radio with cassette stereo (wagon models)
22 Ash tray
23 Transmission gear shift lever (wagon models)
24 Brake pedal

*where fitted

Steering Column Controls

Ignition Lock

This is an anti-theft lock and is on the right side of the steering column. It has four positions.

LOCK: The key can be inserted or removed only when the switch is in this position. The safety button should be pressed when the key is returned to "LOCK" from "ACC" or "ON" position.

ACC (1st forward from Lock)— Permits operation of accessories when the engine is not running.

ON (2nd Forward from Lock) — Normal operating position. The ignition circuit and the electrically operated instruments are energised.



START: (3rd forward from Lock)— Turning the key to this position will start the engine. The key returns to "ON" position when released.

CAUTION: Do not turn the ignition switch away from the "ON" position while the vehicle is in motion as this renders ineffective any power assisted equipment.

Never turn the key to the Lock position whilst the vehicle is in motion as this will lock the steering.

STEERING WHEEL: Avoid turning the steering wheel while the vehicle is stationary. NEVER move the vehicle with the steering locked, or damage to the steering assembly will result.

PARKING: When leaving your vehicle unattended:

1. Apply the parking brake.
2. Place transmission selector in Reverse or First gear.
3. Turn key to LOCK position.
4. Remove key.
5. Check the lights.
6. Lock all doors and windows.

NOTE: If the steering lock is difficult to disengage when the vehicle has been parked with the tyres hard up against the kerb or with the steering wheel off-centre it may be necessary to rotate the steering wheel to free up the ignition steering lock.

HORNS

The horn is operated by pressing either of the two buttons on the steering wheel.



'Tilt' Steering Wheel (where fitted)

The steering wheel is adjustable in the back and forth direction. Adjust the steering wheel position together with the driver seat for maximum comfort.

Fully tighten the lock lever after marking the adjustment. Always make adjustments with the vehicle stationary and NEVER attempt to adjust while driving.

Adjustment procedure:

1. To release, turn the lock lever clockwise
2. Sit on the seat in the proper position and adjust the steering wheel to the desired position by moving the steering wheel forward and backward.
3. At the desired position, rotate the lock lever to the lock direction to tighten securely.





Combination Light Switch

This controls the light switch, turn signal switch, dipping switch and passing light switch.

Turn Signals

Move the switch lever in direction of a turn being made so that the external turn signal lights operate causing turn signal indicator light on the instrument panel to flash. The switch lever returns automatically to neutral position when steering wheel is returned to straight ahead position.

Light switch

To turn on the parking lights, tail lights, licence plate lights, and instrument panel lights, turn the switch knob clockwise to the first stop.

To turn on the headlights and other lights, turn the switch knob clockwise to the next stop.

Headlamp Dipping

The headlight beam is alternately switched from low to high or high to low each time the switch lever is moved towards the steering wheel and released.

The headlight high beam indicator on the instrument panel lights up, when the headlights are on high beam.







Passing light switch

The headlight high beam turns on and goes out each time the switch lever is moved towards steering wheel and released with the light switch in either "OFF" or "1st" position.

To give a signal of overtaking operate the lever repeatedly so that the headlights are made to flash in daytime and alternately switch from low to high beams at night.

Windshield Wipers and Washers

Wiper Operation (Front)—The windshield wipers are operated by turning the end of the stalk clockwise.

The switch has 3 positions to control the wipers.

① Off
② Intermittent (where fitted)
③ Low speed
④ High speed

Do not operate the wipers if the windshield is dry. It may scratch the windshield glass. Do not operate wipers if they are caked with snow or frozen as it may damage the wiper system.

Washer Operation (Front)—By depressing the button on the end of the stalk the electric washer pump is activated, spraying jets of fluid onto the area swept by the wiper blades, and will only continue while the button is depressed.







Windshield washer tank

The tank should be filled only with plain water or AC Delco Optikleen washer solution. (Part No. M37068.)

Hazard warning switch

When the switch button is pushed in, the entire turn signal lights are made to flash regardless of the turn signal switch position. The hazard warning flasher switch is to be used ONLY when your vehicle has become a traffic hazard.

USE OF THE HAZARD WARNING SYSTEM WHILE THE VEHICLE IS MOVING IS PROHIBITED BY LAW IN SOME STATES.

Electric Digital Clock

Time is displayed when the starter switch is in the "ON" position. To reset the time, push the switches as necessary. The function of each switch is as follows:

"MIN" : Minute indication is advanced rapidly while this switch is pushed.

"HOUR" : Hour indication is advanced rapidly while this switch is pushed.

"SET" : Minute indication is reset to "00" when this switch is pushed.

If the reset switch is pushed when the display is 1:01-1:29, the clock reset hour will be reset to 1:00, when the display is 1:30-1:59, the clock will be reset to 2:00.







Transmission Control

This system has five fully synchronised forward gears and a non-synchronised reverse gear.

First Gear — Low: This is synchronised and so can be engaged at low speeds when necessary.

Second Gear — Low Intermediate: Use this gear in traffic and steep hills.

Third Gear — High Intermediate: Use this gear for accelerating and retarding in traffic and to maintain speed on hills.

Fourth Gear — High: This is the normal cruising gear for city and suburbs. A lower gear should be selected for accelerating or retarding.

Fifth Gear — Use this gear for highway cruising above 80 km/h but use fourth gear when acceleration or retardation is required.

Reverse Gear — This gear must never be engaged unless the car is stationary.

Back-Up Lights — These will operate whenever Reverse is selected, provided the ignition switch is in the ON position.

Always use 1st or Reverse gear when starting from rest.

NOTE:

To ensure minimum exhaust emissions and fuel consumption shift the gears at the following speeds:

From 1st to 2nd — 15 km/h
2nd to 3rd — 30 km/h
3rd to 4th — 50 km/h
4th to 5th — 60 km/h



Wagon models

Van models



Back door window wiper

Depress the switch to operate the back door window wiper. **Do not operate the wipers if the back door window is dry. It may scratch the window glass. Do not operate wipers if they are caked with snow or frozen as it may damage the wiper system.**

Back door window washer switch

Push and hold the switch button so that the washing solution is squirted on to the back door windshield.



Back door window washer tank

The washer tank is installed in the inside panel at the left rear wheel arch.

The tank should be filled only with plain water or AC Delco Optikleen.

Back door window demister

With the starter switch on, depress the switch knob to use the back door window demister. The indicator light turns on when this switch is in use. When the back door window becomes clear turn off by depressing the switch again.

If the switch is left on, the battery will discharge. A warning light located above the switch turns on when the demister is operating.







Meters and indicator lights



① Brake fluid level indicator light
② Speedometer
③ Odometer
④ Trip counter
⑤ Turn signal indicator lights
⑥ High beam indicator light
⑦ Generator indicator light
⑧ Temperature gauge
⑨ Fuel gauge
⑩ Parking brake indicator light
⑪ Oil pressure indicator light
⑫ Fuel empty warning indicator light (where fitted)

Speedometer

The speedometer indicates the vehicle speed in kilometres per hour (kph).

Odometer

The odometer registers the accumulated distance in kilometres.

The black figures on the extreme right indicate 0.1 kilometre.

Trip meter

A reset knob for trip distance is located in speedometer lower centre section.

To reset trip counter, push the knob in.

Temperature gauge

The gauge indicates the engine coolant temperature and normal engine coolant temperature is indicated when the gauge reading is around 80°C. If the gauge indicates overheating condition, stop the vehicle and keep the engine running at idle until coolant temperature lowers to normal level.

Determine cause of overheating and rectify before proceeding.

Fuel Gauge

The fuel gauge indicates the level of fuel within the fuel tank when the starter switch is turned on. The letters "F" and "E" represent "Full" and "Empty" respectively.







Turn signal indicator lights

Oil pressure indicator light

Generator indicator light

High beam indicator light

PARK BRAKE Parking brake indicator light

BRAKE Brake fluid indicator light

Low fuel indicator light (where fitted)

Turn Signal Indicator Lights

When the turn signal switch or hazard warning flasher switch is turned on, the turn signal indicator light flashes to indicate operation of the external turn signal or hazard warning flasher.

Oil Pressure Indicator Light

The oil pressure warning light turns on when the starter switch is turned on but before the engine is started. **If the oil pressure indicator light comes on while driving, it indicates that the oil pressure is dangerously low. Stop the engine immediately and check level of oil in the engine crankcase. If the oil level is normal have the lubricating system checked at your nearest dealer.**

Generator Indicator Light

The generator indicator light lights up when the starter switch is turned on but before the engine is started. The generator indicator light lights up when generator circuit fails.

If the generator indicator lights turn on while driving, have the generator circuit checked at your nearest GMH dealer.

High Beam Indicator Light

The high beam indicator light turns on when headlight high beams are in use.

Parking Brake Indicator Light

With the ignition switch in the ON position, the warning light will operate while the brake is on or not fully released.

When the brake has been fully released the parking brake warning light in the instrument panel will go out.

Never drive the vehicle with the warning light on.

Brake Fluid Level Indicator Light

The brake indicator light indicates the level of brake fluid in the reservoir. With starter switch in "ON" position, the light turns on when the brake fluid in the reservoir is lower than the specified level indicating need for immediate replenishment.

(See page 72.)

Low Fuel Indicator Light (where fitted)

The light will come on when the level in the fuel tank is down to approximately five litres. You should refuel as soon as possible.

Floor Controls

Accelerator Pedal

To avoid unnecessary increase in fuel consumption, the accelerator pedal should be operated smoothly.

Clutch Pedal

The clutch pedal should be fully depressed when disengaging. If this is not done, grating of the gears may result.

Do not allow your foot to rest on the pedal when not using the clutch.

Brake Pedal

Avoid hard stops by operating the foot brake pedal in a smooth manner. When descending a slope, it is always advisable to use the foot brakes in combination with the engine braking effect.

Parking Brake Lever

To apply the parking brake pull out the lever. To release, turn the lever clockwise and push it back into home position. **Never drive with parking brake set as this may overheat or otherwise damage parking brake mechanism.**





Radio (van models)

(AM)

1. ON/OFF switch and volume control:
   Push the volume control to switch the receiver on, a second push will switch the receiver off. Turn the control to increase or decrease volume.
2. Tone Control:
   Turn to control tone.
3. Manual tuning control:
   The receiver may be tuned at any time by means of manual tuning control, this will not affect the pre selected stations on push controls.
4. Preset Tuning Buttons:
   Push button in to tune into a pre selected station.



Preset tuning buttons can be preset in the following manner:
(a) Unlock the push button by firmly pulling outwards.
(b) Accurately tune the receiver to the required station with manual tuning control.
(c) Lock push button to the station by pushing in slowly and completely.

AM/FM Radio with Cassette

(wagon models)



1 Program switch
2 Stop/eject button
3 Cassette tape insertion slot
4 Fast-forward & rewind buttons
5 Power/front & rear speaker adjust switch
6 Tone control knob
7 Radio tuning dial
8 Left/right speaker adjust knob
9 Stereo indicator
10 AM/FM selection buttons
11 Tape selection button
12 Dolby NR
13 Search button
14 Loudness button

PROGRAM SWITCH
When this is pressed, the direction of tape transport is reversed, and a new selection is heard.

STOP/EJECT BUTTON
When this is pressed once the tape stops, and when pressed again the tape is ejected.

TAPE SELECTION BUTTON
Depress this button when using metal or chrome tapes.
For normal tapes, keep this button out.

DOLBY NR
Depress this button when playing a tape recording using DOLBY NR to decrease the noise.

VOLUME ADJUSTMENT/ POWER SWITCH
- When pressed once the power is turned on, and when pressed again power is turned off. Rotate to adjust the volume.
- Pull out and rotate to adjust the balance between the front and rear speakers. When rotated toward the F side, the volume of the front speakers increases, and when rotated toward the R side, the volume of the rear speakers increases.

STEREO INDICATOR
This indicator lights when the FM station being received is in stereo.

SEARCH BUTTON
Depress the FF or REW buttons after depressing this button to forward the tape to the beginning of the following selection or rewind to the beginning of the current selection.

LOUDNESS BUTTON
Depress this button to increase bass and treble when the volume is low.

* "Dolby" and the Double D symbol are trademarks of Dolby Laboratories Licensing Corporation.

Ventilation and Heating System

The vehicle features a flow-through ventilation system for your comfort. Under reasonable conditions, it shouldn't be necessary to open the windows at any time. Fresh air is ducted into the vehicle through the plenum chamber in front of the windshield.

Rear Heater (where fitted)

By turning the switch, hot air is delivered from the heater outlets, when the main switch is in "Rr.HEATER" position. Air flow can be controlled in 2 steps.

Heater Demister

The functions of the heater when the engine is running are as follows:
Heating.
Windshield demisting.
Ventilation.

Air outlet select lever positions

1. "Face": Air to face level.
2. "Bi-level": Air to face and foot levels.
3. "Foot": Air to foot level.
4. "Defrost": Air to windshield and side windows for demisting.

Air-Source select lever positions

5. "Circ": Air recirculated in the vehicle.
6. "Fresh": Outside air brought into the vehicle.

Temperature lever positions

7. "COLD": Low temperature.
8. "HOT": High temperature is variable between hot and cold limits.

Fan blower switch

9. The blower fan switch controls the volume of air delivery in three steps.





How to Use The Controls

Ventilation

Set air source lever to "Fresh" to obtain outside air. Air flow may be boosted by using the fan.

Select air outlet temperature control positions as desired.

If outside air is not required for any reason, set the air source lever to "Circ" (such as driving on a dusty road).

Heating

Set the temperature control lever to obtain the required temperature. Set air outlet select lever to direct the heated air where it is required. For rapid heating set the air source lever to "Circ" and use fan.

For normal heating air source select lever may be set for "Fresh" position. If vehicle is moving use of fan is optional.

Windshield defrosting and defogging

To defog the windshield in summer set the Temperature lever at "COLD" and the Select lever at "DEF".

Set the Fan lever at "HI". To defrost or defog the windshield in winter set the Temperature lever at "HOT" and the Select lever at "HEAT". Operate system for 30 seconds to remove humid air from the system, then set the Select lever at "DEF" and the Fan lever at "HI". Both in summer and winter operate the system with the air Source lever set in position of "FRESH".

Starting and Driving

The following suggestions are for starting and driving and should be followed if you are to get the best out of your vehicle.

Parking Brake

This should be firmly applied, and released only after you have started the engine.

Transmission

Press the clutch in and select neutral in the transmission.

Starting Engine

1. Pump the accelerator pedal 2 or 3 times and release it.
2. Depress the clutch pedal all the way to floor, hold and crank the engine by turning the starter switch fully clockwise.

   Release the key as soon as the engine starts. The starter switch will return automatically to "on" position.
3. When the engine starts, allow it to run at fast idle for approximately 20 to 30 seconds to facilitate warming-up.

   If the engine does not start with the carburettor flooded, continue to operate the starter motor with the accelerator pedal depressed to floor.

Do not keep the starter motor engaged for more than 15 seconds at a time.

Wait 30 seconds before trying again. If the starter motor has been operated continuously but the engine did not start, allow 30 seconds before attempting to restart. If the engine fails to start with repeated cranking, check fuel system and electrical system.

Initial Driving

Depress the clutch pedal and place the gear shift lever into the first or the reverse gear position according to requirements. Release the parking brake. Lightly depress the accelerator pedal to increase the engine speed and slowly release the clutch pedal to set the vehicle in motion.

If the Engine Fails to Start with Initial Cranking

IMPORTANT: Do not keep the starter engaged for more than 15 seconds at a time. Wait 30 seconds and try again.

Note: If the starting motor has been operated continuously but the engine did not start, allow 30 seconds before attempting to restart. If the engine fails to start with repeated cranking, check fuel system and electrical system.

Step light (where fitted)
The light turns on when either of the front door, sliding door and back door (WAGON only) are opened.

Dome Light (van models)

The dome light is operative at any starter switch position.

① "OFF" position: The light remains out.
② "DOOR" position: The light turns on when the door is opened.
③ "ON" position: The light turns on regardless of the door position.

Dome Light (wagon models)

The dome light is operative at any starter switch position.

① "OFF" position: The light remains out.
② "DOOR" position: The light turns on when the door is opened.
③ "ON" position: The light turns on regardless of the door position.







Four-Way Hazard Warning Flasher

- Use the warning flasher to warn other drivers any time your vehicle becomes a traffic hazard, day or night.
- Turn on the hazard warning flasher, with engine ignition off or on, by pushing the button located on the right side of the steering column.
- To cancel the flasher, pull the button out.

USE OF THE HAZARD WARNING SYSTEM WHILE THE VEHICLE IS MOVING IS PROHIBITED BY LAW IN SOME STATES.

Spare Wheel Storage

The spare wheel is secured to the rear part of the underbody by a chain. To lower the spare wheel insert the handle into the hole in the rear face of the vehicle just above the rear step. Engage the winch and turn the handle anti-clockwise to lower. Turn the handle clockwise to securely hold the wheel in the stowed position. After the wheel is secured turn the handle one additional turn.





Wheel Changing

The jack is stowed in the jack compartment in the front of the side step. The jacking handle rod is installed on the step wall panel, except for the wagon where it is installed under the second seat in clips provided.

The rod extension for the jack is in the toolkit and can be used whenever necessary.

Tool set is stowed at rear of driver seat, except for wagon where it is stowed under the second seat.







Instructions

1. Park on a level surface and firmly put on the parking brake. Activate the hazard warning flashers and set transmission in reverse.
2. Block the wheel diagonally opposite to the jacking position. Loosen the wheel nuts slightly. Don't remove them.
3. Using the jack handle position the jack under the vehicle according to the illustration.
4. Operate the jack by placing the square end of the jack handle into the recess provided and turn the handle clockwise to raise the vehicle until the tyre clears the ground.



5. Remove the wheel nuts and change the wheel.
6. Tighten the wheel nuts with your fingers then with the wrench in the order shown. Lower the vehicle until the wheel touches the ground and is held from rotating. Fully tighten the wheel nuts using the sequence illustrated.
7. Completely lower the vehicle and remove the jack using the handle in the bracket provided.



Safety Hints

1. Carefully follow jacking instructions in order to reduce the possibility of serious personal injury.
2. The jack is designed for use ONLY when changing wheels.
3. Never get beneath the vehicle when supported by the jack only.
4. Do not start or run the engine while the vehicle is on the jack only.
5. All Passengers should be out of the vehicle when it is on the jack and the handbrake should be firmly applied.

CAUTION: As soon as practical, after a wheel change, the wheel nut torques should be checked at a GMH Dealership, or by another competent person, to ensure correct tightness.

Emergency Starting

Starting With Auxiliary (Booster) Battery

To start the vehicle when the battery is discharged, use a single auxiliary battery of the same nominal voltage, i.e. 12 volts, as the discharged battery, with suitable jumper cables.

CAUTION:
Never expose battery to open flame or electric spark—battery action generates hydrogen gas which is flammable and explosive. Don't allow battery fluid to contact skin, eyes, fabrics, or painted surfaces—fluid is a sulphuric acid solution which could cause serious personal injury or property damage. Wear eye protection when working with battery.

Both booster and discharged battery should be treated carefully when using jumper cables. Follow exactly the procedure outlined below, being careful not to cause sparks. (See Fig.)

1. Set parking brake and place transmission in neutral. Turn off lights and other electrical loads.
2. Remove vent caps from both the booster and the discharged batteries. Lay a cloth over the open vent wells of each battery. These two actions help reduce the explosion hazard always present in either battery when connecting "live" booster batteries to "dead" batteries.
3. Attach one end of one jumper cable to the positive terminal of the booster battery (identified by a red colour, "+" or "P" on the battery case, post or clamp) and the other end of same cable to positive terminal or discharged battery. Do NOT permit vehicles to touch each other, as this could establish a ground connection and counteract the benefits of this procedure.
4. Attach one end of the remaining negative (−) cable to the negative terminal (black colour, "−" or "N") of the booster battery, and the other end to the negative post of dead battery—taking care that clamps from one cable do not touch the clamps on the other cable. Do not lean over the battery when making this connection.
5. Start the vehicle with discharged battery.
6. Reverse this sequence exactly when removing the jumper cables. Reinstall vent caps and discard cloths as these may have corrosive acid on them.

CAUTION:
Any procedure other than the above could result in: (1) personal injury caused by electrolyte squirting out the battery vents, (2) personal injury or property damage due to battery explosion, (3) damage to the charging system of the booster vehicle or of the immobilised vehicle.

Do not attempt to jump start a vehicle having a frozen battery because the battery may rupture or explode. If a frozen battery is suspected, examine all fill vents in the battery. If ice can be seen or if the electrolyte fluid cannot be seen, do not attempt to start with jumper cables as long as the battery remains frozen.



Push Starting

- NEVER TOW the vehicle to start because the surge forward when the engine starts could cause a collision with the tow vehicle.
- When being pushed to start the engine, turn off all unnecessary electrical loads, turn starter switch to "ON", depress the clutch pedal and place the shift lever in high gear. Release the clutch pedal when speed reaches 15-25 km/h. Bumpers and other parts contacted by the pushing vehicle should be protected from damage during pushing.

Towing

Proper lifting or towing equipment is necessary, when lifting or towing the vehicle to prevent damage to it during any towing operation. Detailed towing information is available at your dealer and has been provided to tow truck operators responsible for movement of disabled or locked vehicles. However, in an emergency, a disabled or locked vehicle may be towed in the following manner:

- Fit the towing rope (safety chains or cables) in the locations as follows;

  Front: tow eye.
  Rear: shackle.
- When a need has arisen for towing your vehicle, release the parking brake and place the transmission in neutral. It is important that the transmission and rear axle are in good operating condition to enable the vehicle to be towed.
- When towing a vehicle with trouble in the rear axle;

  It is necessary to tow the vehicle with the rear wheels lifted and to disconnect the propeller shaft, or to lift the rear wheels when towing a vehicle with transmission trouble.

Towing a Disabled Vehicle

Freeing Vehicle From Sand, etc.

If it becomes necessary to rock the vehicle to free it from sand, mud or snow, move the gear shift lever from second to reverse gear. Do not race engine. For best possible traction, avoid spinning wheels when trying to free the vehicle. Use of tyre chains is recommended for temporary assistance when traction is lost on ice or snow.

CAUTION:
Wheel spin should not exceed 55 km/h as indicated on the speedometer. Unless care is taken in limiting rear wheel spin, one spinning wheel can reach excessive speeds, resulting in possible tyre disintegration or differential failure, which could cause personal injury or extensive vehicle damage.

Towing by a Tow Rope Type attachment

The tow rope and safety chains must be attached to tow eye at the front. Make certain that the rope attachment to the tow vehicle is as low as possible.

For the sake of safety and to prevent damage to the vehicle and tow rope it is advisable to avoid jerky movements and to drive slowly during towing operations.

It is always preferable to have a vehicle towed by a tow truck. If this is not possible heed the following cautions.

Never tow a vehicle on four wheels with the ignition switch in LOCK or ACC.

Never tow a vehicle at speeds over 40 km/h.

Don't attach lifting hooks or chains to bumper bars or bumper brackets, or to any damaged part of the vehicle.

Only the driver should be in a towed vehicle.

Vehicles with damaged transmissions must not be towed unless the propeller shaft has been removed.

Towing by Tow Truck

The vehicle should be raised until the lifted wheels are a minimum of 10 cm from the ground, care should be taken to ensure adequate ground clearance at the opposite end of the vehicle.

In cases of rear end damage it may be necessary to lift the rear end of the vehicle and tow on the front wheels only. In such cases the steering wheel must be clamped in the straight ahead position using a clamping device designed for towing service use, such as those provided by towing equipment manufacturers. **Do not use the vehicle's steering column lock for this purpose.**

Overheating

When Indicator light comes on;
When Temperature gauge indicates HOT;
If excessive hot water or steam appears from Engine Compartment.

If this happens, stop by the road side and let the engine idle for about two minutes. Then turn it off and open the engine cover.

While the engine is cooling, check your fan belt for slipping or breakage and check for damage to the radiator hoses. Take care as the hoses will be hot.

Radiator Surge Tank

The radiator surge tank is provided near the battery. Coolant level is checked by opening the battery check cover on the floor near the sliding door.



Check the level of coolant and replenish at the radiator surge tank. When the level of coolant within the surge tank is found to be lower than "MIN" line of its capacity, check the cooling system for leaks, then replenish to bring the level up to the "MAX" line.

Do not overfill the surge tank. The radiator filler cap should not be removed unless necessary. The coolant level should be checked while the engine is cold. Supplement inhibitors or additives claiming to provide increasing cooling capability that have not been specifically approved by GMH are not recommended for addition to the cooling system. It is the owner's responsibility to keep the freeze protection at a level commensurate with the temperatures which may occur in the area of vehicle operation.

CAUTION: DO NOT remove the radiator cap while the engine is still hot because the cooling system will blow out scalding fluid and steam under pressure which is likely to cause serious personal injury and loss of coolant.

When Oil Pressure Indicator Light Comes On

- If the oil pressure indicator light comes on while engine is running, immediately stop engine.

CAUTION: Do not run the engine at high speed when the oil pressure indicator light is on, otherwise the engine may be damaged.

- Check the level of the engine oil and check for leakage of lubricating oil at the same time. Replenish with proper engine oil up to the specified level, if necessary, and restart the engine to see that oil pressure indicator light goes out.

  If the oil pressure indicator light does not go out even with sufficient level of lubricant in the crankcase, or lubricant is leaking, obtain assistance from your GMH dealer.

When Charge Indicator Light Comes On

- This indicates that the alternator is not generating. Immediately stop your vehicle and check for loose or broken fan drive belt. If loose, adjust belt tension. If the belt is found broken, or if the fan belt is not responsible for the trouble, have your GMH dealer inspect and correct the fault.

CAUTION: Driving under this condition will eventually discharge the battery. If the fan belt is loose or broken, overheating of engine will result. DO NOT drive for an extended period of time if the charge warning light is on.

When an Electrical Device is Inoperative

- If chassis electrical trouble is encountered without extreme damage to any electrical parts, check for burned out fuse, broken wire, poor connections or poor grounding and correct as necessary.

NOTE: The fuse box is located near the ash tray. 'Flip' the cover downwards. (For amperage of fuses, refer to "Specifications" in the later section.)

CAUTION: When replacing a fuse be sure to use a fuse of the specified amperage. Never install a wire or similar for replacement as it may cause a fire hazard to the vehicle.



- If the cause of trouble cannot be located through the above checks and trouble persists, contact your nearest GMH dealer.

When Brake Light Comes On

When the brake indicator light on the instrument panel turns on while driving, the fluid reservoir should be filled to the level mark. Use only recommended hydraulic brake fluid. (See lubricants.)

If fluid level continues to drop as brakes are used have a GMH Dealer inspect and correct the fault IMMEDIATELY.



Emission Control Systems

IMPORTANT: This is an explanation of the operation of the emission control systems fitted to your new vehicle.

Introduction

There are three areas from which pollutants are emitted:

(a) Exhaust System
(b) Crankcase
(c) Fuel System.

A number of controls have been installed by General Motors-Holden's Limited to control the amount of pollutants emitted from your new vehicle.

The following has been produced to assist you in understanding their function by briefly explaining the operation of the various components involved.

Sources of Emissions

During the combustion process in an automotive engine, some of the fuel (hydrocarbons) fails to burn and is discharged into the engine crankcase or exhaust system. Additionally hydrocarbons are emitted into the atmosphere through evaporation of petrol vapors from the fuel tank and carburettor. Of the total hydrocarbons coming from uncontrolled automobiles, about 25% are emitted from the crankcase, 20% from the fuel system and 55% from the engine exhaust.

In addition to hydrocarbons, carbon monoxide and oxides of nitrogen are also formed during the combustion process. These are also discharged into the exhaust system.

Vehicle Emission Control Information Label

This label is located on the floor in front of and below the outboard passenger's seat under the floor mat and provides all relative specifications required to correctly tune the engine of your Shuttle.

VEHICLE EMISSION CONTROL INFORMATION

ENGINE TUNE-UP CONDITIONS
MAKE IDLE SPEED AND TIMING ADJUSTMENTS WITH ENGINE AT NORMAL OPERATING TEMPERATURE CHOKE OPEN AIR CLEANER INSTALLED AND DISTRIBUTOR IDLE COMPENSATOR AND EGR VACUUM LINES DISCONNECTED AND PLUGGED AND TRANSMISSION IN NEUTRAL.
RECONNECT THE VACUUM LINES WHEN ADJUSTMENTS ARE COMPLETED.
SET PARKING BRAKE AND BLOCK DRIVE WHEELS.
IDLE SPEED AND IDLE MIXTURE SETTING PROCEDURE
1. TURN THE IDLE MIXTURE ADJUST SCREW ALL THE WAY IN AND BACK OUT 2½ TURNS.
2. ADJUST THROTTLE. ADJUST SCREW TO 850 RPM.
3. ADJUST SETTING OF IDLE MIXTURE ADJUST SCREW TO ACHIEVE THE MAXIMUM ENGINE SPEED.
4. RESET THROTTLE ADJUST SCREW TO 830 RPM.
5. TURN IDLE MIXTURE ADJUST SCREW CLOCKWISE (LEAN) UNTIL ENGINE IDLE SPEED IS DOWN TO 800 RPM.

IGNITION TIMING SETTING PROCEDURE
1. SET SPECIFIED IDLE SPEED.
2. CONNECT TIMING LIGHT LEAD TO NUMBER 1 CYLINDER.
3. ALIGN MARK ON CRANKSHAFT PULLEY TO TIMING MARK WITH TIMING LIGHT AIMED TOWARD TIMING MARK.

CAUTION: REMOVAL OF ADJUSTMENT CAP AND ALTERATION TO OTHER THAN SPECIFIED IDLE MIXTURE SETTING MAY VIOLATE STATE LAWS. SEE SERVICE MANUAL FOR FURTHER INFORMATION.

ENGINE	IGNITION TIMING	PLUG GAP	IDLE SPEED	
L4 1994	6° BTDC	0.75 mm	800 RPM	Part No. 8944192960

Service Replacement Parts

The emission control systems of your new vehicle were designed, built and tested using GM parts and the vehicle is certified as being in conformity with Australian Design Rules covering emissions. Accordingly, it is recommended that any replacement parts used for required maintenance services or for the repair of emission control systems be new GM parts. Use of replacement parts which are not of equivalent quality may impair the effectiveness of such systems, and may adversely affect your vehicle Warranty.



Section 4

Customer Assistance and Authorised GMH Dealers

We want you to be happy with your new Shuttle and with the people you deal with while you have the vehicle.

Normally, any problems which may arise with the sales transaction, operation or servicing of your vehicle will be handled by your Dealer's Sales and Service department.

We realise however that, with the best intentions, misunderstandings do occur sometimes.

If you have a problem that has not been settled to your satisfaction here's what to do:

Step 1:

Discuss the problem with one of the Dealer's management people. If you feel you haven't got satisfaction from the Sales Manager or Service Manager — go to the General Manager or the Dealer himself.

Step 2:

If it seems that no-one at the dealership can help fully, write to the Zone Customer Assistance Manager in your State outlining your problem and including your name, address and telephone number; the vehicle model number and vehicle identification number; the vehicle delivery date and odometer reading and the Dealer's name and address. This information will be on your Warranty Certificate.

Step 3:

By now you should have satisfaction. If not, you can write to the National Customer Assistance Manager, GMH Sales Pty Ltd, Box 548D, G.P.O., Melbourne 3001.

Always try to sort things out at the Dealership. Customer Assistance Managers will have to refer the problem back to the Dealer.

GMH
Customer Assistance Managers

QUEENSLAND
General Motors-Holden's Sales Pty. Ltd.,
Box 728, G.P.O.,
BRISBANE, QLD. 4001.

NEW SOUTH WALES AND AUSTRALIAN CAPITAL TERRITORY
General Motors-Holden's Sales Pty. Ltd.,
Box 481, P.O.,
EDGECLIFF, N.S.W 2001.

VICTORIA AND TASMANIA
General Motors-Holden's Sales Pty. Ltd.,
Box 548D, G.P.O.,
MELBOURNE 3001.

SOUTH AUSTRALIA AND NORTHERN TERRITORY
General Motors-Holden's Sales Pty. Ltd.,
Box 221, P.O.,
ELIZABETH, S.A. 5112.

WESTERN AUSTRALIA
General Motors-Holden's Sales Pty. Ltd.,
P.O. Box 426,
WEST PERTH, W.A. 6005.

Authorised GMH Dealers

(Note: Dealership names and locations listed are effective at the time of printing. These may change from time to time without notice.)

NEW SOUTH WALES — Metropolitan Dealers

ARNCLIFFE
Suttons Motors (Arncliffe) Pty. Ltd.,
93 Princes Highway

ASHFIELD
Muirs Motors (Ashfield) Pty. Ltd.,
252 Parramatta Road

BALGOWLAH
Mitchell Cox Holden
164 Condamine Street

BAULKHAM HILLS
Tony Packard Holden
Cnr. Victoria Avenue & Windsor Road

BELMONT
Challenge Holden
444 Pacific Highway

BLACKTOWN
West City Motors
120-128 Sunnyholt Road

CABRAMATTA
Ron Hodgson Holden
266 Hume Highway

CAMPBELLTOWN
Paul Wakeling Holden
63 Blaxland Road

CARDIFF
Brian Kelly Holden
35-39 Macquarie Road

CHULLORA
Suttons Motors (Chullora) Pty. Ltd.,
Cnr. Hume Highway & Waterloo Road

CROW'S NEST
J. N. Caldwell (Holdings) Pty. Ltd.,
1 Alexander Street

DEE WHY
Barry Smith Holden
Cnr. May and Mooramba Roads

GORDON
Sundell Holden
836 Pacific Hwy. & McIntyre St.

GOSFORD
Noble Motors
Pacific Highway

HOMEBUSH
Suttons Motors (Homebush)
112 Parramatta Road

HOMEBUSH
Gilbert & Roach Pty. Ltd.
167-173 Parramatta Road

KINGSFORD
John Pellegrini Holden
263-271 Anzac Parade

LAKEMBA
Nash Holden
1018 Canterbury Road

LIVERPOOL
A. C. McGrath & Company
Cnr. Castlereagh St. & Hume Highway

MIRANDA
Greg Ball Holden
1-3 Kiora Road

NEWCASTLE
Young & Green Pty. Ltd.,
745 Hunter Street

PADSTOW
Purnell Bros. Holden
19 Davies Road

PARRAMATTA
Fair Deal Car Sales Parramatta
65 Church Street

PARRAMATTA
Hillsdon's Pty Ltd.,
87 Church Street

PENNANT HILLS
Les Vagg Holden
351-355 Pennant Hills Road

RANDWICK
Boyded Randwick
265 Avoca Street

ROCKDALE
C. V. Holland
571 Princes Highway

RYDE
Muirs Motors (Ryde) Pty. Ltd.,
603-605 Victoria Road

SPRINGWOOD
Kerry's Motors Pty. Ltd.,
28 Great Western Highway

ST. MARY'S
Lance Motors Pty. Ltd.,
Corner Glossop & Harris Streets

TORONTO
Young & Green (Toronto) Pty. Ltd.,
Carey Street

VILLAWOOD
John A. Gilbert
766 Woodville Road

WAITARA
Suttons Motors
90 Pacific Highway

WARILLA
Wilson's Warilla Pty. Ltd.,
29 Shellharbour Road

Hawkesbury Valley Motors
122 George Street

WOLLONGONG
Dwyers Pty. Ltd.,
31-33 Crown Street

WYONG
W. M. Holden
Pacific Highway

NEW SOUTH WALES — Country Dealers & Service Dealers

Consult your local Yellow Pages under Motor Cars — New for Addresses and Telephone Numbers.

- ADELONG
- ALBURY
- ARDLETHAN
- ARMIDALE
- BALLINA
- BARADINE
- BARHAM
- BARRABA
- BATHURST
- BEGA
- BELLINGEN
- BLAYNEY
- BOMBALA
- BOURKE
- BOWRAL
- BREWARRINA
- CANOWINDRA
- CASINO
- CESSNOCK
- COBAR
- COFF'S HARBOUR
- COLLARENEBRI
- CONDOBOLIN
- COOLAMON

- COOMA
- COONABARABRAN
- COONAMBLE
- COOTAMUNDRA
- COROWA
- COWRA
- CROOKWELL
- CULCAIRN
- DENILIQUIN
- DORRIGO
- DUBBO
- DUNGOG
- EDEN
- FINLEY
- FORBES
- GILGANDRA
- GLEN INNES
- GLOUCESTER
- GOULBURN
- GRAFTON SOUTH
- GRENFELL
- GRIFFITH
- GULARGAMBONE
- GUNDAGAI
- GUNNEDAH
- GUNNING
- GUYRA
- HARDEN
- HAY
- HOLBROOK
- INVERELL
- JERILDERIE
- JUNEE
- KANDOS
- KATOOMBA
- KEMPSEY
- KIAMA
- KURRI KURRI
- KYOGLE
- LAKE CARGELLIGO
- LEETON
- LISMORE
- LITHGOW
- MACKSVILLE
- MACLEAN
- MAITLAND
- MILTON
- MOLONG
- MOREE
- MORUYA
- MUDGEE
- MULLUMBIMBY
- MUNGINDI
- MURWILLUMBAH
- MUSWELLBROOK
- NARRABRI
- NARRANDERA
- NARROMINE
- NOWRA
- NYNGAN
- ORANGE
- PARKES
- PEAK HILL
- PORT MACQUARIE
- QUIRINDI
- SCONE
- SINGLETON
- TAMWORTH
- TAREE
- TEMORA
- TENTERFIELD
- TUMBARUMBA
- TUMUT
- TWEED HEADS
- WAGGA
- WALCHA
- WALLA WALLA
- WALGETT
- WARIALDA
- WARREN
- WAUCHOPE
- WELLINGTON
- WEST WYALONG
- WINGHAM
- WOODENBONG
- YASS
- YOUNG

VICTORIA — Metropolitan Dealers

BENTLEIGH
Boyanton Holden
280 Centre Road

BERWICK
Neil & Ross Holden
755 Princes Highway

BRAYBROOK
Kevin Dennis Holden
272 Ballarat Road

BUNDOORA
Davies Dwyer Pty. Ltd.,
413 Grimshaw Street

BURWOOD
Dustings Hillyer Holden
1200 Toorak Road

CAULFIELD
Booran Holden
1049 Glenhuntly Road

CHELSEA
Harrison Holden
370 Nepean Highway

CHELTENHAM
Balmoral Holden
1212 Nepean Highway

DANDENONG
Patterson Cheney Pty. Ltd.
200 Cheltenham Road

DANDENONG
Graeme Blanchard Holden
Princes Highway

DONCASTER
Lance Dixon Holden
610 Doncaster Road

ELSTERNWICK
Reg Hunt Motors Pty. Ltd.,
77 Nepean Highway

ESSENDON
Preston Motors (Essendon) Pty. Ltd.,
201-211 Keilor Road

FAWKNER
M. & G. Mantello Holden
1263 Sydney Road

FERNTREE GULLY
Neilson Holden F.T.G.
980 Burwood Road

FOOTSCRAY
Patterson Cheney Pty. Ltd.,
130 Moreland Street

FOOTSCRAY
Alan Mance Holden
435 Barkly Street

FRANKSTON
Noel Gould Holden
140 Dandenong Road

GEELONG
R. & B. Smith Pty. Ltd.,
510 Moorabool Street

GEELONG
Winter & Taylor (Sales) Pty. Ltd.,
23 Cavendish Street

GLEN WAVERLEY
Geoff Brady Holden
565-577 Springvale Road

HASTINGS
McRae Motors Pty. Ltd.,
762 Flinders Road

HEIDELBERG WEST
Arthur Ellis Holden
66 Bell Street

LILYDALE
Noel Dight Holden
Main Street

MORNINGTON
Peninsula Holden
Cnr. Nepean Highway & Tyabb Road

OAKLEIGH
Garry & Warren Smith Pty. Ltd.,
1575 Dandenong Road

PRESTON
Graham Hunt Holden
518 High Street

RINGWOOD
Patterson Cheney Holden
45-57 Maroondah Highway

SOUTH MELBOURNE
Patterson Cheney Holden
132 Sturt Street

WERRIBEE
Ballan Holden
Princes Highway

WEST MELBOURNE
Reg Hunt Motors
577 King Street

VICTORIA — Country Dealers & Service Dealers

Consult your local Yellow Pages under Motor Cars — New for Addresses and Telephone Numbers.

- ALEXANDRA
- ARARAT
- BACCHUS MARSH
- BAIRNSDALE
- BALLARAT
- BENALLA
- BENDIGO
- BIRCHIP
- BOORT
- CAMPERDOWN
- CASTERTON
- CASTLEMAINE
- CHARLTON
- COBRAM
- COHUNA
- COLAC
- COLERAINE
- CORRYONG
- DAYLESFORD
- DERRINALLUM
- DIMBOOLA
- DONALD
- ECHUCA
- EUROA
- HAMILTON
- HOPETOUN
- HORSHAM
- KANIVA
- KERANG
- KOOWEERUP
- KORUMBURRA
- KYABRAM
- KYNETON
- LEONGATHA
- MAFFRA
- MANSFIELD
- MARYBOROUGH
- MILDURA
- MINYIP
- MORTLAKE
- NATHALIA
- NHILL
- NULLAWIL
- NUMURKAH
- NYAH
- PORTLAND
- QUAMBATOOK
- RAINBOW
- ROCHESTER
- RUTHERGLEN
- SALE
- SEA LAKE
- SEYMOUR
- SHEPPARTON
- ST. ARNAUD
- STAWELL
- SWAN HILL
- TALLANGATTA
- TIMBOON
- TRARALGON
- UNDERBOOL
- WANGARATTA
- WARBURTON
- WARRACKNABEAL
- WARRAGUL
- WARRNAMBOOL
- WODONGA
- WONTHAGGI
- YARRAM
- YARRAWONGA

AUSTRALIAN CAPITAL TERRITORY

CANBERRA CITY
Beazley & Bruce (ACT) Pty. Ltd.
44 Mort Street

FYSHWICK
Beazley & Bruce (ACT) Pty. Ltd.
96 Newcastle Street

WODEN
Commonwealth Motors Pty. Ltd.
58 Melrose Drive

QUEENSLAND — Metropolitan Dealers

ALBION
Bill Harrison Car Sales
Frodsham Street & Crosby Road

ASPLEY
Zupps (Aspley) Pty. Ltd.,
1442 Gympie Road

CLEVELAND
Russell Smith Holden
Cnr Queen & Doig Streets

IPSWICH
Zupps Holden
246 Brisbane Road, Booval

MOOROOKA
John Sivyer Holden
1060 Ipswich Road

MT. GRAVATT
Zupps Motors
1310 Logan Road

NEWSTEAD
Eagers Retail Pty. Ltd.,
95 Breakfast Creek Road

NUNDAH
Eagers (Northside)
1319 New Sandgate Road

PETRIE
North Pine Motors Pty. Ltd.,
Gympie Road

REDCLIFFE
Village Holden
425 Elizabeth Avenue

ROCKLEA
Task Motors
1696 Ipswich Road

SPRINGWOOD
Midways Holden
Pacific Highway & Brennan Street

WINDSOR
Leach Holden
146 Newmarket Road

WYNNUM
Doug Barton Holden
200 Tingal Road

QUEENSLAND — Country Dealers & Service Dealers

Consult your local Yellow Pages under Motor Cars — New for Addresses and Telephone Numbers.

- ATHERTON
- AUGATHELLA
- AYR
- BEAUDESERT
- BEERWAH
- BLACKALL
- BOWEN
- BUNDABERG
- CABOOLTURE
- CAIRNS
- CALOUNDRA
- CHARLEVILLE
- CHARTERS TOWERS
- CLERMONT
- CLONCURRY
- CROWS NEST
- CUNNAMULLA
- DALBY
- DIRRANBANDI
- EMERALD
- GATTON
- GAYNDAH
- GLADSTONE
- GOONDIWINDI
- GYMPIE
- HUGHENDEN
- INGHAM
- INNISFAIL
- JULIA CREEK
- KILCOY
- KINGAROY
- LAIDLEY
- LONGREACH
- MACKAY
- MAREEBA
- MARYBOROUGH
- MITCHELL
- MONTO
- MORANBAH
- MOURA
- MT. ISA
- MURGON
- NAMBOUR
- NANANGO
- NOOSA HEADS
- PROSERPINE
- QUILPIE
- ROCKHAMPTON
- ROMA
- SOUTHPORT
- SPRINGSURE
- STANTHORPE
- ST. GEORGE
- TOOWOOMBA
- TOWNSVILLE
- TULLY
- WARWICK
- WINTON
- YULEBA

SOUTH AUSTRALIA — Metropolitan Dealers

ADELAIDE
City Holden
203-221 Grenfell Street

ADELAIDE
United Motors Retail Ltd.
72 Franklin Street

ELIZABETH
Peter Page Holden
Elizabeth Way

GLENELG
John H. Ellers Pty. Ltd.,
282 Brighton Road

MALVERN
Claridge Motors Pty. Ltd.,
361-367 Unley Road

MILE END
United Motors Co. Pty. Ltd.,
71 West Beach Road

PORT ADELAIDE
Smith Motor Co. Pty. Ltd.,
171 Commercial Road

REYNELLA
Brian Gill Holden
49-59 Main South Road

SOUTH AUSTRALIA — Country Dealers & Service Dealers

Consult your local Yellow Pages under Motor Cars — New for Addresses and Telephone Numbers.

- BALAKLAVA
- BERRI
- BURRA
- CEDUNA
- CLARE
- CLEVE
- CRYSTAL BROOK
- CUMMINS
- GAWLER
- JAMESTOWN
- KADINA
- KEITH
- KINGSCOTE
- KINGSTON
- LAMEROO
- LOXTON
- MAITLAND
- MALLALA
- MENINGIE
- MILLICENT
- MINLATON
- MT. BARKER
- MT. GAMBIER
- MURRAY BRIDGE
- NARACOORTE
- ORRORO0
- PORT AUGUSTA
- PORT LINCOLN
- PORT PIRIE
- QUORN
- RENMARK
- STRATHALBYN
- TANUNDA
- VICTOR HARBOUR
- WAIKERIE
- WHYALLA
- WUDINNA
- YANKALILLA
- YORKETOWN

WESTERN AUSTRALIA — Metropolitan Dealers

BELMONT
Major Motors
255 Great Eastern Highway

CANNINGTON
Brian Gardner Holden
1308 Albany Highway

FREMANTLE
Shack Motors
64 Queen Victoria Street

GOSNELLS
Lance Gibbons Holden
2325 Albany Highway

MANDURAH
Estuary Holden
1 Gibson Street

MELVILLE
Melville Motors Pty. Ltd.,
532-536 Canning Highway

MIDLAND
John Goldie Holden
161 Great Eastern Highway

MORLEY
Metro Motors Pty. Ltd.,
212 Walter Road

NAVAL BASE
Shacks Cockburn
Rockingham

OSBORNE PARK
North City
Cnr. Scarborough Beach Rd. & Harbourne Street

PERTH
City Motors
505 Newcastle Street

VICTORIA PARK
Young's Holden
529 Albany Highway

WANNEROO
Phoenix Holden
316 Berriman Drive

WESTERN AUSTRALIA — Country Dealers & Service Dealers

Consult your local Yellow Pages under Motor Cars — New for Addresses and Telephone Numbers.

- ALBANY
- BEVERLEY
- BRIDGETOWN
- BROOKTON
- BRUCE ROCK
- BUNBURY
- BUSSELTON
- CARNAMAH
- CARNARVON
- COLLIE
- CORRIGIN
- CRANBROOK
- DALWALLINU
- ESPERANCE
- EXMOUTH
- GERALDTON
- GNOWANGERUP
- GOOMALLING
- KALGOORLIE
- KAMBALDA
- KATANNING
- KELLERBERRIN
- KOJONUP
- KUNUNURRA
- MANJIMUP
- MERREDIN
- MOORA
- MT. BARKER
- NAREMBEEN
- NARROGIN
- NORSEMAN
- NORTHAM
- PINGELLY
- PINJARRA
- PORT HEDLAND
- WAGIN
- WILLIAMS
- WYALKATCHEM

TASMANIA — Metropolitan & Country Dealers & Service Dealers

HOBART
Motors Pty. Ltd.,
179 Macquarie Street

BURNIE
Motors Pty. Ltd.,
84-89 Marine Terrace

DEVONPORT
Motors Pty. Ltd.,
628 Victoria Parade

KING ISLAND
King Island Motors Pty. Ltd.,
Netherby Road, Currie

LAUNCESTON
Motors Pty. Ltd.
165 Brisbane Street

SMITHTON
Motors Pty. Ltd.,
16 Nelson Road

ULVERSTONE
Motors Pty. Ltd.,
99 Reibey Street

NORTHERN TERRITORY — Dealers

ALICE SPRINGS
Kittle Bros. (Alice Springs) Pty. Ltd.,
Cnr. Wills Terrace & Railway Terrace

DARWIN
Suttons Motors (Darwin) Pty. Ltd.,
Cnr. Mitchell and Knuckey Streets

Section 5:

SERIAL NUMBERS:

V.I.N. PLATE:

Vehicle identification plate:
It is attached to the floor in front of and below driver's seat under the floor mat.



Chassis number:
It is stamped on the floor near the driver's seat.



Engine number location:
Stamped on pad front right side of engine block.



Tyre Pressure Placard:
Tyre inflation pressure placard is located adjacent to the driver's seat.



Main Data and Specifications

	Short Wheel Base	Long Wheel Base
DIMENSIONS mm		
Wheel base	2,350	2,690
Tread: Front	1,430	
Rear	1,400	
Minimum ground clearance	185	
Minimum turning radius	4,800	5,400
WEIGHT kg	2730 (185R14LT-8PR TYRES)	
G.V.M. (Permissible)	2300 (185SR14-4PR TYRES)	
G.C.M.		
Trailer without independently controlled brakes	3,000	
With independently operated trailer brakes	3,650	
Axle capacity: Front	1,250	
Rear	1,600	
ENGINE:		
Model and type	PETROL 4ZCI 4 cycle, water cooled SOHC carbureted gasoline	
Compression ratio (to 1)	8.3	
Piston displacement cc	1994	
Valve clearance (at cold)		
Intake mm	0.15	
Exhaust mm	0.25	
Ignition timing degree/rpm	6° BTDC/800	
Firing order	1 3 4 2	

	ALL MODELS
ENGINE (Continued)	
Distributor contact point gap mm	0.2 - 0.4
Spark plug gap mm	0.75
Head bolt tightening torque Nm	98
Engine oil capacity	3.2 to 3.7 litres
add for filter	0.4
Coolant capacity litres	9.0
Fuel tank capacity litres	60
CLUTCH	
Type	Hydraulic control, dry single plate with diaphragm springs
Pedal free play mm	20 to 30
TRANSMISSION	
Model and type	MSG 5K 5 speed, fully synchronized transmission

Gear ratio (to 1)	1st	2nd	3rd	4th	5th	Rev.
Petrol	4.122	2.493	1.504	1.000	0.855	3.753

Lubricant capacity (litres)	1.55
Filler and drain plug tightening torque Nm	39

REAR AXLE	
Type	Banjo semi floating
Gear ratio	41/9 (4.555)
Oil capacity (litres)	1.5
STEERING	
Type	Recirculating ball
Steering wheel free play mm	10 to 30
Oil capacity	
— manual	0.48 litres
— power	1.7 litres
Wheel alignment	
Toe-in mm	1 to 7
Camber	35′
Caster	2° ± 30′
King pin angle	7°25′
SERVICE BRAKE	
Type	Hydraulic disc in front, self adjusting drum brake in rear with vacuum servo
Pedal free play mm	7 to 10
PARKING BRAKE	
Type	Mechanical internal-expanding, acting on rear wheels
Brake lever travel (notches)	12 to 14 (when pulled with a force of 30 kg)

SUSPENSION	
Type, Front mm	Independent wish bone arms, coil spring with stabilizer bar and hydraulic double acting telescopic shock absorbers
Rear	Semi-elliptical alloy steel leaf spring with double-acting hydraulic telescopic shock absorbers.
ELECTRICAL	
Type	12 volts system with negative polarity ground
Battery volt/amp. hr.	N40 (12/40)
Starter volt/kw	12/0.8
AC generator volt/amp. hr.	12/55
WHEELS	5.0J x 14 — Van & Window Van 5.5J x 14 — Wagon
TYRES	185R14LT-8PR — Van & Window Van 185SR14-4PR — Wagon

Tyre inflation pressure (cold) kPA

		Front	Rear
185R14LT-8PR	Unladen	275	235
	Laden	300	415
185SR14-4PR	Unladen	215	215
	Laden	215	215

Bulb Replacement

Headlights

Proper aiming of the headlights is most important to assure correct illumination of the highway without blinding other motorists. Headlamp aiming or replacement should be carried out by your GMH Dealer.

Front parking lights

Remove screws retaining the lens and remove the lens. To remove light bulb, push it in and turn anticlockwise.

Front and side turn signal lamps

Remove screws retaining the lens and remove the lens. To remove light bulb, push it in and turn anticlockwise.



Rear Combination Lights

Remove screws retaining the lens and remove the lens. Bulb socket sequence from the top downward is, Turn Signal Light, Stop and Tail Light, Back-Up Light.



Dome Lights

Access to bulb can be obtained by removing the two screws.

Licence Plate Lights

Remove screws retaining the lens and remove the lens.



Fuse System

When replacing a bulb, make sure it has the correct wattage rating. Standard bulb wattage ratings are given below.

	Wattage
Headlight (Halogen or Sealed beam)	65/55
Parking Lamp	5
Turn signal lights	21
Side turn lights	5
Tail/Stop light	5/23
Turn signal light	23
Back up light	23
Licence plate lights	5
Dome light	10
Step lights (where fitted)	5

Fuse junction block

The fuse junction block is installed near the ash tray. The cover can be pulled out easily with hand.

If a fuse has been blown check to locate the cause of trouble and give necessary service attention before replacing the fuse.

When replacing the fuse, use a cartridge of the same amperage.





Circuit	Amperage
1. AM Radio	15
2. Front cigarette lighter	15
3. Rear cigarette lighter*	15
4.	
5.	
6.	
7. Front wiper, Front washer	15
8. Rear wiper, Rear washer	15
9. Turn signal, Backup light, Gauge, Indicator lights	15
10. Engine	15
11.	
12.	
13.	
14. Rear heater*	15
15. Rear defogger	15
16.	
17. Front heater	20
18. Hazard warning lights, Dome light, Digital clock*	15
19.	
20. Horn, Stop lights	15
21.	
22.	
23. Right tail lights	10
24. Left tail lights	10

* where fitted

Fusible Link Wires

If the headlights or other electrical components do not work and the fuses are O.K., check the fusible link wires.

If a fusible link wire is melted, it must be replaced.

Always use genuine GMH fusible link wires for replacement.

Never use wire—even for a temporary fix. It may cause extensive damage and possibly a fire.

If there is an overload in the circuits from the battery, the fusible link wires are designed to melt before the entire wiring harness is damaged.

The cause of electrical overload should always be determined before replacing the fusible link wires.

PETROL



Section 6: Appearance, Maintenance and Service

Paintwork

The paint on your Shuttle is finished in acrylic enamel and will stay bright and new-looking provided you wash and wax it regularly, using approved products. Weekly washing is recommended if the vehicle is being used constantly or if it is not parked under cover.

Before you wash the paintwork, thoroughly wash in and around the front and rear windows and check that door drain holes, tailgate drain holes and rocker sill vents are clean. Hose off any heavy dirt on the glass, but leave final cleaning of the glass until last.

Washing tips

Use either cold or warm water — preferably running.

Use clean chamois cloths, sponges or rags (old, clean linen is better than new material for glass).

Don't wash your vehicle in bright sunlight — it will streak.

Grease and oil can be removed with a little kerosene or white spirits. Flush with water afterwards.

If petrol is spilled during refilling, flush with water immediately.

Be sure that your cleaner, polish or wax is suitable for acrylic finishes. AC Delco Wash & Wax from your GMH Dealer is highly recommended.

Insect spots can be removed with a mixture of 220 grams of baking soda in 2 litres of water. Flush clean afterwards. New tyre look can be restored with AC Delco Tyre Black from your GMH Dealer.

Tarnished chrome responds well to AC Delco Polishing Liquid.

Oil

CAUTION: As with any machinery, extreme care should be taken when carrying out any inspections or maintenance job. If you have any doubts about your own ability, please have the job done by a qualified mechanic.

Initial Oil Fill

A high quality SE oil was installed in your petrol engine at the factory. It is not necessary to change this factory-installed oil prior to the recommended normal change period. However, check the oil level more frequently during the running-in period since higher oil consumption is normal until the piston rings become seated.



NOTE: Non-detergent and other low quality oils are specifically not recommended. Only the use of SE or SF engine oils and proper oil and filter change intervals assure you of continued proper lubrication of the engine.

Maintaining Oil Level

The oil level indicator is marked ADD and FULL. The oil level should be maintained between the two markings, neither going above the FULL marking nor under the ADD marking. Check the oil level frequently and add oil when necessary.

To check the oil level accurately, the vehicle must first be on level ground and the engine should be stopped for at least ten minutes. Checking the oil level too soon after stopping the engine will not allow sufficient time for oil, which has circulated to the upper parts of the engine, to drain back into the engine oil pan, and consequently, a false low reading will be obtained. Topped up under these conditions will result in the oil pan being over-filled.

Remove the indicator, wipe it clean with clean cloth or paper before reinserting it firmly. Pause for a second then withdraw the indicator to check the reading of the oil level.

The distance between the ADD and FULL marks represent approximately 1 litre on all engines. Oil level should be checked more often during the running-in period since somewhat higher oil consumption could be experienced until piston rings become seated.

Oil Consumption

In many cases, it is erroneously thought that engines should not use any noticeable amount of oil between oil changes. In actual fact every internal combustion engine should use a certain amount of oil to act as a lubricating and cooling agent especially during the running-in period.

There are several factors that contribute to oil consumption, apart from mechanical malfunction, that should be noted, and these are: the type of oil, the seating of piston rings, the oil level, and the conditions under which the vehicle is operated.

Running-in

The initial factory-fill oil should remain in the engine for the recommended period. (Refer this section.) Oil consumption may be high during the running-in period.

Lubrication

An engine is dependent on oil to lubricate the cylinder walls, pistons, rings and valve stems. A film of oil is left on the cylinder walls and burned on the next firing stroke while the film on the valve stems is drawn into the combustion chamber and burned. These quantities, while small, explain why an engine does use some oil.

Oil Level

Maintaining a proper oil level is also an important factor in controlling oil consumption. An overfull crankcase allows the reciprocating parts of an engine to splash oil on to the cylinder walls in quantities greater than the piston rings can control. This excess oil will be drawn into the combustion chambers and burned.

Overfilling the crankcase can result if the oil level indicator markings are not understood. (Refer to previous notes.)

Dilution

Probably the most prevalent complaint of oil consumption comes from the motorist whose vehicle is driven at below normal operating temperatures for long periods of time. The oil becomes diluted by fuel and moisture which settle in the crankcase, raising the oil level and creating a false reading on the oil level indicator. For example, in a vehicle that has accumulated 1500 kilometres of city operation and has consumed a normal amount of oil, the level may not have dropped from the FULL mark, due to dilution. If this vehicle is then driven for some distance at highway speeds on a warm day, the dilution elements evaporate, lowering the oil level and the motorist assumes the oil is being lost.

Speed Consumption

Sustained high engine speeds will increase oil consumption because higher speeds increase engine temperatures which lower oil viscosity and allow more oil to reach the combustion chamber.

If it is considered that the above possibilities can be accounted for but excessive oil consumption appears to continue, then it is recommended that you discuss the situation with a GMH Dealer.

NOTE: Non-detergent and other low quality oils are specifically not recommended. The use of break-in oils, tune-up compounds, friction-reducing compounds and other supplemental additives are not recommended; their use will only increase operating costs.

REMINDER: The use of proper engine oils and observing oil change intervals are your best assurance of continued reliability and performance from the engine of your vehicle.

In the event of an operational problem, consult your GMH Dealer for advice before using supplemental additives.

Oil Filter Replacement

The full-flow oil filter, with non-return check-valve, filters all the engine oil delivered by the oil pump. For this reason the interval of filter change is very important.

The oil filter should be replaced as shown in the maintenance schedule.

Under prolonged dusty driving conditions it is recommended that the oil filter be replaced more often.

NOTE: After the oil filter has been replaced, additional oil must be added.

Always use AC brand of oil filters, for replacement purposes.

Fuel Requirements

The vehicle is designed to operate on a good quality clean unleaded fuel of 91 octane rating. The use of a fuel which is too low in anti-knock property will result in "Detonation" (a metallic rapping noise generated during the combustion process). If "Detonation" persists, consult an authorized GMH Dealer. Continued operation of an engine which exhibits symptoms of "Detonation", may result in damage for which General Motors-Holden's Sales Pty. Limited is not responsible under the terms of the Warranty.

Oil Change Intervals

The amount of time between changes depends a lot on what you use the vehicle for, and where it is driven.

The table indicates oil change intervals for vehicles used ''normally''.

If you usually drive on dusty roads; if you often take long trips; or—strangely enough—if you only use your vehicle for short trips, you will need to change the oil more often. Say every month or every 2,500 kilometres.

NORMAL OPERATING CONDITIONS	
Prevailing Daytime Temperatures	**Regular Oil Change Interval**
ABOVE 10°C	**EVERY 3 MONTHS OR 5000 KM — WHICHEVER OCCURS FIRST**
BELOW 10°C	**EVERY 1 MONTH OR 2500 KM — WHICHEVER OCCURS FIRST**

It is recommended that you see your GMH Dealer for advice on the frequency of oil and filter changes under unusual driving conditions.

Lubrication

Lubricants should be carefully selected according to the lubrication chart. It is also important to select viscosity of lubricants according to the atmospheric temperature by referring to the following table.

ENGINE OIL
Use SE engine oil.

NOTE: Non-detergent and other low quality oils are specifically not recommended. The use of SE engine oils and proper oil and filter change intervals promote continued reliability and performance from your engine.
The proper oil viscosity also helps cold and hot starting.



*In engine use correct grade oil. SE grade

Transmission Oils Power Steering Fluid (where fitted)

Manual Transmission

Check the oil level every six months or 10,000 kilometres whichever comes first—and add oil to the level of the plug hole if necessary.

The oil should be changed at the one month or 1,000 km service, then every two years or 40,000 kilometres.

Rear Axle

This should be checked every six months or 10,000 km whichever comes first. If necessary, add oil to bring the level of the oil to the plug hole.

The oil should be changed at the 1,000 km service, then every 40,000 kilometres.



The fluid reservoir is located on the right side of the engine when the engine cover is opened (refer page 14).



The fluid level must be maintained between the limits. If the supply is insufficient, remove the cap and add ® Dexron 11D Automatic Transmission Fluid.

Lubricants

Petrol engine crankcase	SF grade engine oil SAE 20W/40
Transmission case	SAE 30 engine oil
Power steering (where fitted)	DEXRON 11D Automatic Transmission Fluid
Manual steering Front axle	Gear Oil GL5 grade to GM-H HN1386 or HN1187 specification
Wheel bearings	Wheel bearing grease to GM-H HN1227 specification
Brake and clutch pedal pivots	Grease to GM-H HN1147 specification
Park brake, universal joint and prop shaft sliding yoke	Grease to GM-H HN1271 specification
Hydraulic brake and clutch system	Hydraulic brake fluid to GM-H HN1796 specification
Engine cooling system	Permanent anti-freeze type (ethylene glycol) to GM-H HN1897 specification 30% anti-freeze to 70% water
Chassis	Water resistant EP type chassis lubricant to GM-H HN1271 specification

Cooling System

This must be serviced regularly if the engine is to operate efficiently.

Rust Protection

High purity water should be used with a GMH approved anti-rust fluid. If you live in an area where water has a high level of mineral or chemical content, use rainwater or distilled water and add GMH HN1897 in correct proportion to cooling system.

If you need to use borewater in an emergency—change it for clean water as soon as possible.

Follow the directions on the pack when adding an anti-rust fluid.

Radiator Pressure Cap

Because of this cap your engine can work at over 100°C without boiling.

If your engine should overheat, refer to instructions on page 43.

Checking Coolant Levels

The level of coolant in the surge tank should be checked regularly such as at refuelling stops. Top up as required. The level in the radiator should be checked **weekly** when the engine is cold. Topping up instructions are given in the following paragraph.

Filling the cooling system

With the engine cold fill the radiator until coolant enters the surge tank via the overflow outlet tube. Fit the radiator cap and start the engine.

During the warm-up period coolant will be expelled from the radiator into the surge tank due to expansion.

When the engine is at normal operating temperature check the coolant level in the surge tank and, if required, top up to the "MAX. Level when hot" position shown on the tank. SUBSEQUENT topping-up of the tank, with the engine hot, should ensure that the radiator is full without having to remove the radiator pressure cap.

Draining and Flushing

Every six months or 10,000 km drain and refill the radiator and add a GMH approved corrosion inhibitor coolant. To drain the radiator—loosen the cap, locate the lower radiator hose and loosen the clamp fastening this hose to the radiator. Now disconnect this hose.

Do not use cleaning chemicals to loosen scale unless the cooling system is afterwards thoroughly reverse flushed, otherwise loosened scale will clog the radiator water passages.

For complete removal of loose sediment and sludge from the radiator and water jacket, pressure flushing with an air and water gun is recommended, and as this method of flushing requires special equipment we suggest you have this work carried out by your GMH Dealer.

Anti-freeze Fluid

This is essential if your car is run for any length of time in snow areas.

The recommended fluid (to GMH HN1897 specification)—can be supplied by your GMH Dealer.

It contains an anti-rust element as well.

If this product is not available and you need to park overnight in a snow area you must drain the main radiator and cylinder case. Otherwise, your radiator may burst or the cylinder case crack.

CAUTION: Draining of the main radiator and cylinder case assembly will not drain the water out of the heater radiator; therefore, the use of Anti-Freeze will eliminate the risk of a damaged heater core.

NOTE: Anti-freeze provides the action of a corrosion inhibitor, eliminating the necessity for a separate additive.

Where a vehicle is to be parked overnight or operated for any length of time in regions where temperatures of 0°C or below are encountered (e.g.—snow areas), the recommended brand of anti-freeze fluid should be used in the cooling system in accordance with the instructions specified.

COLD WEATHER DRAINING

If the recommended brand of anti-freeze fluid is not available, the radiator, and cylinder case, MUST be drained before parking to prevent the possible bursting of the radiator, or cracking of the cylinder block which can occur if the coolant freezes.

CAUTION: Draining of the main radiator and cylinder case assembly will not drain the water out of the heater radiator; therefore, the use of Anti-freeze will eliminate the risk of a damaged heater core.

Corrosio.. Inhibitor HN1897 (PART No. M39338)

MIXING INSTRUCTIONS

The recommended quantity, for the particular engine, should be added to a bucketful of water and stirred before pouring the water into the radiator. Then complete the filling of the cooling system with water. It is not recommended that water be added to a container, into which the inhibitor has first been poured.

COLOUR INDICATIONS

Initially, the inhibitor will cause a pale transparent green colouration to the water. After some time the colouration may change to greenish-yellow. In either case, these colours indicate that the cooling system is being protected by the inhibitor.

NEW RADIATOR PROCEDURE

Where a new radiator is fitted, use inhibitor HN1897 and drain after the first 6 months or 10,000 kilometres.

Brake Master Cylinder

Every 6 months or 10,000 kilometres check the fluid level in the master cylinder. The fluid level visible through the reservoir should be maintained between the MIN and MAX level markings. If the fluid is between these levels do not remove master cylinder cap. If the master cylinder requires constant topping up it could indicate that a malfunction exists in which case it should be immediately brought to the attention of your servicing GMH Dealer.

Use brake fluid to GM-H specification HN1796.

Battery (12 volt)

The battery is located in the floor behind the front passenger seat (see diagram on page 40) and the negative (–) terminal is "grounded". Never disconnect the battery or generator when the engine is running. Always connect Positive (+) to Positive (+), Negative (–) to Negative (–) whenever a battery charger is used.

Fluid Level

The battery fluid level should be maintained at 1 cm above the plates by adding distilled water. Distilled water will be required more frequently in summer than in winter. It is a good plan to check the fluid level at about 1 month intervals in Summer and two months in Winter. When long daylight runs are made, water may need to be added still more frequently. Do NOT overfill, particularly when cold, as subsequent operation at higher temperatures and on long distance driving may cause loss of acid. Keep all battery terminals clean and tight.

When cleaning batteries, wash first with a dilute ammonia or soda solution to neutralize any acid present. Then flush off with clean water. Care must be taken to keep the vent plugs tight so that the neutralizing solution does not enter any cells. Dry off the affected area of the body, battery mounting and retainer, then repaint with paint resistant to sulphuric acid. After reconnecting battery cables, apply a thin coating of petroleum jelly to the battery posts and cable clamps to help retard corrosion.

CAUTION: Never expose a battery to open flame or electric spark—battery action generates hydrogen gas which is flammable and explosive. Don't allow battery fluid to contact skin, eyes, fabrics, or painted surfaces—battery fluid is a sulphuric acid solution which could cause serious personal injury or property damage. Flush any contacted area immediately with water. WEAR EYE PROTECTION SUCH AS INDUSTRIAL SAFETY SPECTACLES OR GOGGLES WHEN WORKING ON OR NEAR A BATTERY. Remove rings, metal watchbands and other metal jewellery before jump starting or working around a battery, and be careful in using metal tools—if such metal should contact the positive battery terminal (or metal in contact with it) and any other metal on the vehicle, a short circuit may occur which could cause personal injury. Batteries and battery acid should always be kept out of the reach of children.

Air Cleaner

The air cleaner element should be removed and cleaned every 6 months or 10,000 km and replaced every 24 months or 40,000 km. If the vehicle is operating in extremely dusty conditions for any length of time the air cleaner should be cleaned more frequently.

Ensure that the thermal vacuum signal hose is connected to the carburettor and air cleaner when re-installing the air cleaner.

CAUTION: Do not remove the engine air cleaner unless temporary removal is necessary during repair or maintenance of the vehicle. When the air cleaner is removed backfiring can cause fire in the engine compartment.

Engine Ventilation Filter

The engine ventilation filter is located in the air cleaner cover.

Every 12 months or 20,000 kilometres clean the engine ventilation intake filter with kerosene or a suitable solvent. Dry with compressed air.

EVAPORATIVE CONTROL SYSTEM

Every 24 months or 40,000 kilometres check all fuel and vapour lines and hoses for proper connections and correct routing as well as condition. Remove canister and check for cracks or damage. Replace damaged or deteriorated parts as necessary. Replace filter in lower section of canister.

WINDSHIELD NOTES

Windshield Cleanliness

It is important, at all times, that the windshield surface be maintained in a clean condition so that the wiper blades may be as effective as possible in wiping clean the surface.

Use of the windshield washer and Optikleen washer solvent will assist in removing dirt and dust particularly when driving at a time when no rain is falling; however, every opportunity should be taken to wipe or wash the windshield by hand (most Service Stations have such a service today as a courtesy item).

Abrasive materials must never be used to remove a build-up of road scum, etc., as a scratched windshield will cause difficulty in achieving proper vision, particularly in night driving. Therefore, after the windshield has been cleaned with a wet sponge, etc., it should be wiped dry with a soft, lint free cloth or even a ball of newspaper.

WIPER WASHER OPERATIONS

Wiper Blades—Cleaning

Much of the oil road scum thrown up onto the windshield glass, causing smearing when the wiper is switched on, transfers onto the wiper blade. Many owners, whilst they methodically clean the windshield glass, omit to clean the wiper blades and consequently smearing of the glass re-appears immediately the wiper blades are set in motion.

The blades can be cleaned by simply lifting them off the windshield glass and then using warm water and a recognised washing fluid. If so desired, the wiper blade can be removed from the arm for cleaning purposes by simply disengaging it from the arm in accordance with the following instructions:—

1. Lift up tab at the end of the arm and remove blade sideways.
2. To replace, slide the blade pin into the hole in the arm clip, noting an audible click.

Washer Reservoir

A plastic reservoir containing liquid for the windshield washer is mounted in the passenger compartment for front wipers left hand rear compartment for rear wipers. It is suggested that when checking the radiator coolant level, the washer reservoir be checked also. For a crystal clear view Optikleen Washer Solvent (Part Number M37068) can be used by adding from the graduated container, the recommended proportion.

CAUTION: Do not operate the wiper blades by hand as this may damage the wiper drive mechanism.

In dry conditions, if the wiper blades are used to clean dust and dirt from the windshield always use the washer system to wet the windshield. Ensure that the windshield washer reservoir is checked regularly all the year round.

Should the wiper blades be frozen to the windshield, it is imperative that they be lifted off and freed by hand before switching on the windshield wiper system.

Tyres

For correct tyre inflation pressures for your vehicle refer page 64.

Always check tyre pressure when the tyres are cold, and always use a tyre pressure gauge. Your eye can deceive.

Tyre Pressure Recommendations

1. Tyre pressures should be checked when the tyres are cold (when the vehicle has been standing for 3 hours or more, or driven less than 2 kilometres).
2. Tyre inflation pressure may increase as much as 4 psi (30 kPa) when hot, (after the vehicle has been driven 15 kilometres or at speeds of more than 95 km/h). DO NOT reduce pressures to compensate for this build up. As a guide for checking warm/hot tyres under all conditions, allow pressure to read 4 psi (30 kPa) above the recommended.
3. It is recommended that the pressures are checked at least weekly. For constant long distance or rough road travelling daily checking is recommended. To maximise the protection of tyres on vehicles operating for prolonged times over rough roads, i.e. particularly in outback conditions, it is recommended that the cold tyre inflation pressure recommended for maximum load condition as shown on the tyre chart be used.
4. Do not forget the spare tyre: It is advisable to maintain the spare at the **maximum recommended tyre inflation pressure listed on the tyre chart.**

Tyre Rotation

If no abnormal or uneven wear is evident, if you have not experienced any vibration, tyres need not be rotated.

Front tyres are more prone to wear on the shoulder while rear tyres wear more on the crown. Wear can be evened out by rotating the tyres.

Check them at the 5,000 km inspection, then at intervals of 10,000 km. Your GMH dealer will be able to diagnose any unusual signs of wear and can also balance the wheels and tyres for you.

RADIAL TYRE ROTATION



Tyre Replacement

Use only tyres recommended. Don't mix cross ply and radial ply tyres on your vehicle and don't mix radial ply tyres with other types of tyres. New tyres should be fitted in pairs to the front but if replacing only one tyre, pair it with the least worn of the old tyres.

And if you replace all tyres with tyres of a different size, your speedometer readings may be affected. Have the car checked afterwards.

Tyres with a higher speed rating and/or with a maximum load rating in excess of that listed on the tyre placard for tyre size listed are also acceptable as replacements provided they are fitted to a suitable rim size.

Uneven or abnormal tyre wear is usually the result of incorrect inflation pressure, improper wheel alignment, wheels being out of balance, or poor driving habits. The original equipment tyres incorporate built-in tread wear bars which act as indicators to assist in determining when the tyres have worn to the point of needing immediate replacement.

When the wear bars appear, tyre replacement should not be delayed, in the interests of safety.

Heavy Treads

Caution must be exercised when using tyres with heavy treads, including tyres designed to gain traction in bad weather conditions.

At sustained high speeds, this type of tyre will run at higher temperatures than standard tyres and consequently should only be operated within the limits recommended by the manufacturer.

Any doubts concerning the fitness of the tyres on your vehicle for the purpose you require should be referred to your GMH Dealer, who will be pleased to advise.

Tyres and Long Distance Motoring

For trouble free motoring the tyres must be in

1. good condition, the walls and treads being free of cuts, stones and abrasions.
2. treads must not be excessively worn, tread pattern should still be visible over the entire tread surface.
3. the tyres should not be retreaded or regrooved.
4. the tyre pressures should be as shown in specification chart.
5. ensure front and rear tyre pairs have comparable wear.

SUGGESTED GUIDE FOR CHECKING HOT TYRES—

As a guide for checking warm/hot tyre "under all conditions", allow pressure to read 4 psi (30 kPa) above that recommended for cold tyre.

Tyre Traction

CAUTION: A decrease in driving, cornering, and braking traction occurs when water, snow, ice, gravel, or other material is on the road surface. Driving practices and vehicle speed should be adjusted to the road conditions.

When driving on wet or slushy roads, it is possible for a wedge of water to build up between the tyre and road surface. This phenomenon, known as hydro-planing, may cause partial or complete loss of traction, which adversely affects vehicle control and stopping ability. To reduce the possibility of traction loss, the following precautions should be observed:

1. Reduce speed levels during rainstorms or when roads are slushy and if the road has standing water or puddles.
2. Replace tyres when tread wear indicators are visible.
3. Check that tyres are properly inflated for vehicle loading.

Tyre Damage and Repair

Tyres with cuts, splits or cracks deep enough to expose the fabric, should be replaced. Bulges also indicate internal damage, and these tyres should also be replaced. Tyres with doubtful damage should be removed from the wheel and examined by a competent person.

If a pressure loss occurs while driving, do not attempt to drive on the deflated tyre more than is necessary to stop safely. Driving even a short distance on a deflated tyre can damage it beyond repair.

When puncturing objects are removed, repairs will have to be made according to the recommendations of the tyre manufacturer.

It should always be remembered that a tyre which has been repaired will not be able to be operated safely at the rated maximum speed and due care should be taken.

Replacement Wheels

When replacing wheels for any reason, care should be taken to ensure that the wheels are equivalent to those removed in diameter, rim width and offset.

Owner's Responsibility

Normal maintenance services, as listed in the servicing schedule contained on pages 85 and 86 in this book, and replacement of servcie items, are the responsibility of the Owner and such are NOT considered, under the provisions of the New Vehicle Warranty, to be rectification of defects in material and workmanship.

Items such as wheel alignment, brake adjustment as a result of lining wear, etc. which may require servicing due to fair wear and tear, will be carried out at the owner's cost.

We strongly recommend that you read the Warranty Certificate at the front of the Owner handbook so that you are conversant with your entitlements.

Water and atmospheric conditions, varying road surfaces, individual driving habits and vehicle usage, greatly contribute to the need for constant maintenance services to promote efficient vehicle operation. (Refer over.)

IMPORTANT
It is the owner's responsibility to have the engine oil changed at 3 month/5,000 km intervals, under normal operating conditions.

Operating Conditions

Normal Conditions

The maintenance instructions contained in this publication are based on the assumption that the vehicle will be used as designed and is operated in accordance with the instruction provided in the owner handbook.

Extreme Conditions

Extreme operating can be described as that where a vehicle operates continually for a period of 1 month or 1000 kilometres under the following conditions:

1 Dust, dirt, loose road metal.
2 Muddy and wet areas.
3 Cold weather—below 10°C.
4 Stop-start, as experienced in inner city driving.
5 Caravan or Trailer hauling.

In such circumstances it is suggested that the following items be serviced more frequently than at the periods recommended in the Guardian Maintenance Plan.

Conditions	Items
1—3—4	Engine oil.
1	Engine oil filter.
1—2	Front suspension, steering, and parking brake system.
5	Automatic transmission fluid.
1	Engine air cleaner element.
2	Front wheel bearings.
2	Manual transmission, drive line joints and rear axle.

If at any time it is considered that the above items or other items should be more frequently serviced due to the type of operation or before a long trip, discuss the situation with the service manager of your GMH Dealer.

Maintenance Plan

The 3-Step Service Concept

The fundamental points are:

1. A basic service interval period of 6 months or 10 000 kilometres whichever occurs first.
2. A "step" principle of 3 correlated services.
3. The frequency of these services is:
   "A" service items — Serviced every 6 months or 10,000 km
   "B" service items — Serviced every 12 months or 20,000 km
   "C" service items — Serviced every 24 months or 40,000 km

Service Designation	—A—	—B—	—C—
Items	Group I *	Groups * I & II	Groups * I, II & III

Up to the 3rd step in the items programmed the earlier steps are included.

The total time/distance range of this Maintenance Schedule is 66 months or 110,000 kilometres.

*See pages 85 and 86 for group definitions.

Total Programme

Pre-Delivery Service
1 Month—1000 Kilometres
Inspection and Adjustment

Then as required: (Months — km)

A @ 6-10,000
B @ 12-20,000
A @ 18-30,000
C @ 24-40,000
A @ 30-50,000
B @ 36-60,000
A @ 42-70,000
C @ 48-80,000
A @ 54-90,000
B @ 60-100,000
A @ 66-110,000

IMPORTANT

It is the owner's responsibility to have the engine oil changed at 3 month/5000 km intervals, under normal operating conditions.

Maintenance

Once the first service has been completed, dependability and performance are influenced by the degree of maintenance the vehicle receives.

Safety, economy and dependability cannot be assured unless regular maintenance is performed, preferably by factory-trained technicians. It is preferable to receive these services from the Dealer from whom the vehicle was purchased. However, Maintenance will be attended to by any Authorised GMH Dealer on presentation of the Maintenance Plan Booklet, no matter where you may be situated.

What The Owner Should Do

When service, according to the time or distance interval, is due, the owner should present this Maintenance Plan Booklet to a GMH Dealer as an authority to have the items listed attended to. After this work is completed, the owner should see that the Validation Record is stamped and signed by the Dealer. The Booklet with the Validations completed is evidence that a vehicle has been adequately maintained. This is important as it will not only assist in the determination of Warranty Claims, but enhance the value of the vehicle whenever resale is contemplated.

What The Servicing Dealer Has To Do

Attend to all items listed for the particular service. When this has been done, it is most important that the Service Coupon be signed by the Dealer or his representative.

All operations listed on the Service Coupons should be carried out following the procedures set out in the appropriate service manual.

The one month — 1000 kilometre service will be performed without cost for labour by the Selling Dealer.

This service may be carried out by another GMH Dealer provided you have a letter of introduction from the Selling Dealer. Your Dealer will supply the necessary letter of introduction upon request.

Maintenance Plan

GROUP I Under Hood Operations
Change engine oil. (Every 5000 km)
Check all fluid levels, accessible in engine compartment, e.g. brake coolant, washer, battery electrolyte, and clutch.
Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
Wipe inside of distributor cap.
Inspect engine air cleaner element for restriction and condition. Replace if necessary.
Check air pre-heat control for correct cold and hot operation.
Check operation of idle stop solenoid.
Check automatic choke for free operation.
First "A" Service Only. Check torque of carburettor mounting bolts Check operation of EGR valve, where fitted
Clean radiator core—check for blockages.
Drain and refill cooling system and recharge with anti-freeze.
First 'A' Service only. Air Conditioner. Check and if necessary adjust compressor drive belt using gauge. Check compressor mounting bolts for tightness. Inspect refrigerant hose connections for evidence of leaks, correct if necessary. Check operation of auxiliary cooling fan.
GROUP I Under Vehicle Operations
Change engine oil filter. (Every 10,000 km)
Check transmission oil level.
Check rear axle oil level.
Inspect and lubricate front suspension and steering joints.
Lubricate transmission shift and clutch linkages as applicable.
Check parking brake operation and lubricate system. Adjust if necessary
Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage— brake and fuel lines, shock absorbers and mountings.
Inspect engine and transmission mountings.
Check and adjust clutch control pedal height.
Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
Inspect disc brake pads for wear.
First 'A' Service. Air Conditioner only Check refrigerant charge at sight glass. Inspect refrigerant hose connections for evidence of leaks, correct if necessary. Check that condenser electric fan is operating.
All 'A' Services After the first
Check refrigerant charge at sight glass.
GROUP I Interior Vehicle Operations
Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
Seat belt inspection. Examine webbing condition, buckle operation and rectractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.
Inspect refrigerant hose connections for evidence of leaks, correct if necessary.
Check operations of blowers.
GROUP I Exterior Vehicle Operations
Lubricate door handle pivots, door hinges, striker bolts or plates and hood lock and catch as required.
Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors, seat adjustment.

Maintenance Plan

GROUP II

GROUP II Under Hood Operations
Lubricate distributor. Check condition of cap and rotor. Check TVRS cables for resistance. Replace spark plugs. Check ignition timing.
EGR System Only. Clean valve and manifold opening.
Auto Choke.* Check and adjust if necessary settings.
Check ignition timing, engine idle speed and fast idle speed on choke cam. Adjust if necessary.
Serviceable PCV Valves—Dismantle, clean and re-assemble. Disposable PCV Valves—Test and replace if necessary
Clean or replace fuel filter as necessary.
Drain and refill cooling system. Add specified quantity of anti-freeze.
Inspect condenser to ensure that it is not clogged with leaves or other foreign material. Check evaporator drain tube for dirt or other restrictions.
Inspect flexible hose lines for leaks and brittleness.
Check timing belt condition.
GROUP II Under Vehicle Operations
Inspect rear brake linings and drums for wear. Wipe off dust. Check self-adjusting mechanism and parking brake adjustment.
Inspect front wheel bearings and check adjustment. Repack only if necessary.
Check steering box. Adjust if necessary.*
Check operation of transmission shift linkage. Adjust if necessary
Inspect flexible hose lines for leaks and brittleness.

GROUP III

GROUP III Under Hood Operations
Replace air cleaner element if not yet changed in previous 24/40 period.
GROUP III Under Vehicle Operations
Repack front wheel bearings.
Inspect steering gear, linkage and dust covers for wear and security Notify owner of any deficiencies, including loss of steering preload, for immediate rectification.
Change transmission and rear axle oil.

N.B. It should be understood that whenever a B or C service is being carried out, some items on an earlier operation, may be superseded or modified by a later operation.

To ensure continued interest in your vehicle, GMH requests that subsequent owners (not original purchaser) fill in and mail one of the attached.

Subsequent Owner Vehicle Identification Certificate

Owner's Name Mr. Mrs. Miss .....

Address .....

Town ..... Phone .....

State & Postcode .....

Reg. No. .....

Vehicle Identification Number (V.I.N.) .....

(Refer Specifications Section of this Manual for location)

Subsequent Owner Vehicle Identification Certificate

Owner's Name Mr. Mrs. Miss .....

Address .....

Town ..... Phone .....

State & Postcode .....

Reg. No. .....

Vehicle Identification Number (V.I.N.) .....

(Refer Specifications Section of this Manual for location)

Place in an envelope and mail to:

The Manager — Warranty Administration,
Service Department,
General Motors—Holden's Sales Pty. Limited,
Box 548D, G.P.O.,
Melbourne,
Victoria. 3001.

Place in an envelope and mail to.

The Manager — Warranty Administration,
Service Department,
General Motors—Holden's Sales Pty. Limited,
Box 548D, G.P.O.,
Melbourne,
Victoria. 3001.

1 Month—1000 Kilometre Inspection and Adjustment

This coupon should not be removed until the vehicle is presented for service.

Owner's Name Mr. Mrs. Miss .....

Address .....

Town & State ..... Postcode .....

Reg. No. ..... Model Name .....

V.I.N. ..... Eng No. .....

Selling Dealer's Stamp & Signature .....

Date of Acquisition .....

This vehicle has been thoroughly checked in accordance with the schedule on the reverse side of this coupon.

Servicing Dealer .....

Town ..... State .....

Owner's Signature .....

---

1 Month—1000 Kilometre Inspection and Adjustment

This vehicle has been thoroughly checked in accordance with the 1 month—1000 kilometre inspection and adjustment.

Dealer .....

Service Manager's Signature .....

Date ..... Odometer Reading .....

1 Month—1000 Kilometre Inspection and Adjustment

Under Hood Operations
Change Engine Oil and Filter Element.
Check all Fluid Levels accessible in Engine Compartment.
Check Manifold Mounting Nuts and Cylinder Head Bolts Tightening Torque.
Adjust Valve Clearances.
Check Air Cleaner Element for Restriction under Extreme Dusty conditions.
Check all Hose Clips in Engine Compartment.
Check Condition and Tension of all Engine Drive Belts—using Tension Gauge.
Check and Adjust Hood Lock and Safety Catch and Lubricate.
Under Vehicle Operations
Lubricate Front Suspension, (Ball and Steering Joints—where applicable).
Change Transmission and Rear Axle Oil.
Inspect all Brake Line Connections and Hoses for Leakage and Clearance.
Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and wheel nut tightening torque.
Check Steering Connections.
Check and Adjust Clutch Control Pedal Height.
Interior Vehicle Operations
Check operation of Instruments, Lights, Hazard Warning, Turn signals, Horn, Windshield Wipers and Washers, Seat Belts, Seat Adjustment Mechanisms and Mirrors.
Check Operation of Parking Brake.
Exterior Vehicle Operations
Check Headlamp Aim, Adjust if necessary.
Check Door Lock Operation, Striker Plates, Handles, etc. and Lubricate.
Road Test Programme
All Rattles, Squeaks, Vibrations and Noises should be checked and rectified.
Check vehicle on the road for even braking and steering, transmission operation, engine response and parking brake operation. Check mirrors and seat adjustment.

Additional Service—refer page 111.

This Inspection and Adjustment will be carried out without charge to the owner except for any lubricants, etc. used. The Designated Servicing Programme is not to be exceeded without the Owner's prior agreement to additional servicing charges.

6 Months or 10,000 km

Dealer .....

Date .....

Odometer .....

Signed .....

A SERVICE

6 Months — 10,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake, coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Wipe inside of distributor cap.
	Inspect engine air cleaner element for restriction and condition. Replace if necessary after testing.
	Check air pre-heat control assembly for correct cold and hot setting.
	Check operation and setting of idle stop solenoid.
	Check torque of carburettor mounting bolts.
	Clean radiator core — check for blockages.
	Check cooling system anti-freeze concentration.
*	Air Conditioner. Check and if necessary adjust compressor drive belt using gauge. Check compressor mounting bolts for tightness. Inspect refrigerant hose connections for evidence of leaks, correct if necessary. Check operation of auxiliary cooling fan.

	Under Vehicle Operations
	Change engine oil filter.
	Inspect and lubricate front suspension and steering joints. (Chassis lubrication as chart)
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage — brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings.
	Check and adjust clutch fork operating rod free travel.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
*	Air Conditioner. Check refrigerant charge at sight glass. Inspect refrigerant hose connections for evidence of leaks, correct if necessary. Check that condenser electric fan is operating.
	Change rear axle oil.

P.T.O.

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.
*	Inspect refrigerant hose connections for evidence of leaks, correct if necessary.
*	Check operations of blowers.

	Exterior Vehicle Operations
	Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and park brake operation. Check mirrors and seat adjustment.

Additional Service—refer page 111.

12 Months or 20,000 km

Dealer .....

Date .....

Odometer .....

Signed .....

B SERVICE

12 Months — 20,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake, coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Adjust valve clearance.
	Check tightness of manifold and cylinder head bolts.
	Lubricate distributor. Check condition of points, cap and rotor. Wipe inside of distributor cap. Check TVRS cables for resistance. Replace spark plugs.
	EGR System Only— Clean valve and manifold opening.
	Check operation of exhaust heat manifold valve for free operation.
	Clean engine ventilation filter with kerosene. Inspect engine air cleaner element for restriction and condition. Replace if necessary after testing.
	Auto Choke — Check and adjust if necessary settings. Check and adjust if necessary fast idle speed on choke cam. Check choke for free operation.
	Check timing belt condition.
	Check air pre-heat control assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
	Replace fuel filter.
	Drain and refill cooling system. Add specified quantity of anti-freeze. Clean radiator care — check for blockages.
*	Inspect condenser to ensure that it is not clogged with leaves or other foreign material. Check evaporator drain tube for dirt or other restrictions.
*	Inspect flexible hose lines for leaks and brittleness.
	Under Vehicle Operations
	Change engine oil filter.
	Check transmission oil level.
	Check rear axle oil level.
*	Inspect flexible hose lines for leaks and brittleness.

P.T.O.

	Inspect and lubricate front suspension and steering joints and steering gear (see chassis lubrication chart).
	Inspect steering gear, linkage and dust covers for wear and security. Notify owner of any deficiencies, including loss of steering preload, for immediate rectification.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage — brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings. Check and adjust clutch fork operating rod free travel.
	Check operation of transmission shift linkage. Adjust if necessary.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
	Inspect rear brake linings and drums for wear. Wipe off dust. Check self-adjusting mechanism and parking brake adjustment.
	Inspect front wheel bearings and check adjustment. Repack only if necessary.
	Check steering box and adjust if necessary.

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.
*	*Wagon Only— Check rear seat movement and lock operation.
	Exterior Vehicle Operations
	Lubricate door handle pivots, door hinges, door slide mechanism, striker bolts or plates, hood catch and side and rear door locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

*Additional Service—refer page 111.

18 Months or 30,000 km

Dealer .....

Date .....

Odometer .....

Signed .....

A SERVICE

18 Months — 30,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Wipe inside of distributor cap.
	Check operation of exhaust heat manifold valve for free operation.
	Inspect engine air cleaner element for restriction and condition. Replace if necessary after testing.
	Check air pre-heat control damper assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
	Check automatic choke for free operation.
	Clean radiator core — check for blockages.
	Drain and refill cooling system and recharge with anti-freeze.

	Under Vehicle Operations
	Change engine oil filter.
	Check transmission oil level.
	Check rear axle oil level.
	Inspect and lubricate front suspension and steering joints.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage — brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings.
	Check and adjust clutch fork operating rod free travel.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
	Check refrigerant charge at sight glass.

P.T.O.

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.
*	*Wagon Only— Check rear seat movement and lock operation.
*	Inspect refrigerant hose connections for evidence of leaks, correct if necessary.
*	Check operations of blowers.

Exterior Vehicle Operations
Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear door locks.
Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

Additional Service—refer page 111.

24 Months — 40,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake, coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Lubricate distributor. Check condition of points, cap and rotor. Wipe inside of distributor cap. Check TVRS cables for resistance. Replace spark plugs.
	EGR System Only— Clean valve and manifold opening.
	Check operation of exhaust heat manifold valve for free operation.
	Replace air cleaner element.
	Auto Choke — Check and adjust if necessary settings. Check and adjust if necessary fast idle speed on choke cam. Check choke for free operation.
	Adjust valve clearance.
	Check tightness of manifold and cylinder head bolts.
	Check timing belt condition.
	Check air pre-heat control assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
	Check and adjust if necessary engine idle speed.
	Serviceable PCV Valves — Dismantle, clean and reassemble. Disposable PCV Valves — Test and replace if necessary.
	Replace fuel filter.
	Drain and refill cooling system. Add specified quantity of anti-freeze. Clean radiator core — check for blockages.
	Evaporative control system. Check all fuel and vapour lines and hoses for proper connections and correct routing as well as condition. Remove cannister and check for cracks or damage. Replace damaged or deteriorated parts as necessary. Replace filter.
	Under Vehicle Operations
	Change engine oil filter.
	Change lubrication in transmission.
	Change rear axle lubrication.
	Inspect and lubricate front suspension and steering joints.
	Drain, refill and bleed brake system.

P.T.O.

Service

	Inspect steering gear, linkage and dust covers for wear and security. Notify owner of any deficiencies, including loss of steering preload, for immediate rectification.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage — brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings.
	Check and adjust clutch fork operating rod free travel.
	Check operation of transmission shift linkage. Adjust if necessary.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
	Inspect rear brake linings and drums for wear. Wipe off dust. Check self-adjusting mechanism and parking brake adjustment.
	Repack front wheel bearings.
	Check steering box and adjust if necessary.

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.

	Exterior Vehicle Operations
	Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear door locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

*Additional Service—refer page 111.

30 Months — 50,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake, coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Wipe inside of distributor cap.
	Check operation of exhaust heat manifold valve for free operation.
	Inspect engine air cleaner element for restriction and condition. Replace if necessary after testing.
	Check air pre-heat control damper assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
	Check automatic choke for free operation.
	Clean radiator core — check for blockages.
	Drain and refill cooling system and recharge with anti-freeze.

	Under Vehicle Operations
	Change engine oil filter.
	Check transmission oil level.
	Check rear axle oil level.
	Inspect and lubricate front suspension and steering joints.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage — brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings.
	Check and adjust clutch fork operating rod free travel.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
*	Check operations of blowers.

P.T.O.

30 Months or 50,000 km

Dealer .....

Date .....

Odometer .....

Signed .....

A SERVICE

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.
*	Inspect refrigerant hose connections for evidence of leaks, correct if necessary.
*	Check operations of blowers.

	Exterior Vehicle Operations
	Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear door locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

Additional Service—refer page 111.

36 Months — 60,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5,000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Adjust valve clearance.
	Check tightness of manifold and cylinder head bolts.
	Change steering gear lubricant.
	Lubricate distributor. Check condition of points, cap and rotor. Wipe inside of distributor cap. Check TVRS cables for resistance. Replace spark.
	EGR System Only— Clean valve and manifold opening.
	Check operation of exhaust heat manifold valve for free operation.
	Inspect engine air cleaner element for restriction and condition. Replace if necessary after testing.
	Auto Choke Check and adjust if necessary settings. Check and adjust if necessary fast idle speed on choke cam. Check choke for free operation.
	Check timing belt condition.
	Check air pre-heat control assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
	Check and adjust if necessary engine idle speed.
	Serviceable PCV Valves — Dismantle, clean and reassemble. Disposable PCV Valves — Test and replace if necessary.
	Replace fuel filter.
	Drain and refill cooling system. Add specified quantity of anti-freeze. Clean radiator core — check for blockages.
*	Inspect condenser to ensure that it is not clogged with leaves or other foreign material. Check evaporator drain tube for dirt or other restrictions.
*	Inspect flexible hose lines for leaks and brittleness.
	Under Vehicle Operations
	Change engine oil filter.
	Check transmission oil level.
	Check rear axle oil level.
	Inspect and lubricate front suspension and steering joints.
	Inspect steering gear, linkage and dust covers for wear and security. Notify owner of any deficiencies, including loss of steering preload, for immediate rectification.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
*	Inspect flexible hose lines for leaks and brittleness.

P.T.O.

	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage — brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings
	Check and adjust clutch fork operating rod free travel.
	Check operation of transmission shift linkage. Adjust if necessary.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
	Inspect rear brake linings and drums for wear. Wipe off dust. Check self-adjusting mechanism and parking brake adjustment.
	Inspect front wheel bearings and check adjustment. Repack only if necessary.
	Check steering box and adjust if necessary.

Interior Vehicle Operations

	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.

Exterior Vehicle Operations

	Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear door locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

**Additional Service—refer page 111.*

42 Months — 70,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake, coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Wipe inside of distributor cap.
	Check operation of exhaust heat manifold valve for free operation.
	Inspect engine air cleaner element for restriction and condition. Replace if necessary after testing.
	Check air pre-heat control damper assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
	Check automatic choke for free operation.
	Check torque of carburettor mounting bolts. Check operation of EGR valve, where fitted.
	Clean radiator core—check for blockages.
	Drain and refill cooling system and recharge with anti-freeze.
	Under Vehicle Operations
	Change engine oil filter.
	Check transmission oil level.
	Check rear axle oil level.
	Inspect and lubricate front suspension and steering joints.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage—brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings.
	Check and adjust clutch fork operating rod free travel.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
*	Check refrigerant charge at sight glass.

P.T.O.

42 Months or 70,000 km

Dealer .....

Date .....

Odometer .....

Signed .....

A SERVICE

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.
*	Inspect refrigerant hose connections for evidence of leaks, correct if necessary.
*	Check operations of blowers.

	Exterior Vehicle Operations
	Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear door locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

Additional Service—refer page 111.

48 Months or 80,000 km

Dealer .....

Date .....

Odometer .....

Signed .....

SERVICE

48 Months — 80,000 Kilometres Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake, coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Lubricate distributor. Check condition of points, cap and rotor. Wipe inside of distributor cap. Check TVRS cables for resistance. Replace spark.
	EGR System Only— Clean valve and manifold opening.
	Check operation of exhaust heat manifold valve for free operation.
	Replace air cleaner element if not yet changed in previous 24/40 period.
	Auto Choke— Check and adjust if necessary settings. Check and adjust if necessary fast idle speed on choke cam. Check choke for free operation.
	Check air pre-heat control damper assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
*	Replace timing belt.
	Check and adjust if necessary engine idle speed.
	Serviceable PCV Valves—Dismantle, clean and reassemble. Disposable PCV Valves—Test and replace if necessary.
	Replace fuel filter.
	Drain and refill cooling system. Add specified quantity of anti-freeze. Clean radiator core — check for blockages.
	Evaporative control system. Check all fuel and vapour lines and hoses for proper connections and correct routing as well as condition. Remove cannister and check for cracks or damage. Replace damaged or deteriorated parts as necessary. Replace filter.

	Under Vehicle Operations
	Change engine oil filter.
	Change lubrication in transmission.
	Change rear axle lubrication.
	Inspect and lubricate front suspension and steering joints.
	Inspect steering gear, linkage and dust covers for wear and security. Notify owner of any deficiencies, including loss of steering preload, for immediate rectification.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Drain, refill and bleed brake system.

P.T.O.

	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage—brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings.
	Check and adjust clutch fork operating rod free travel.
	Check operation of transmission shift linkage. Adjust if necessary.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
	Inspect rear brake linings and drums for wear. Wipe off dust. Check self-adjusting mechanism and parking brake adjustment.
	Repack front wheel bearings.
	Check steering box and adjust if necessary.

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.
	Exterior Vehicle Operations
	Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear door locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

Additional Service—refer page 111.

54 Months or 90,000 km

Dealer .....

Date .....

Odometer .....

Signed .....

A SERVICE

54 Months — 90,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake, coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Wipe inside of distributor cap.
	Check operation of exhaust heat manifold valve for free operation.
	Inspect engine air cleaner element for restriction and condition. Replace if necessary after testing.
	Check air pre-heat control damper assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
	Check automatic choke for free operation.
	Check torque of carburettor mounting bolts. Check operation of EGR valve, where fitted.
	Clean radiator core—check for blockages.
	Drain and refill cooling system and recharge with anti-freeze.
	Under Vehicle Operations
	Change engine oil filter.
	Check transmission oil level.
	Check rear axle oil level.
	Inspect and lubricate front suspension and steering joints.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage—brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings.
	Check and adjust clutch fork operating rod free travel.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
*	Check refrigerant charge at sight glass.

A Service

P.T.O.

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiences observed for immediate rectification.
*	Inspect refrigerant hose connections for evidence of leaks, correct if necessary.
*	Check operations of blowers.

	Exterior Vehicle Operations
	Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear door locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

Additional Service—refer page 111.

60 Months or 100,000 km

Dealer .....

Date .....

Odometer .....

Signed .....

B SERVICE

60 Months — 100,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake, coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Lubricate distributor. Check condition of points, cap and rotor. Wipe inside of distributor cap. Check TVRS cables for resistance. Replace spark.
	EGR System Only— Clean valve and manifold opening.
	Check operation of exhaust heat manifold valve for free operation.
	Inspect engine air cleaner element for restriction and condition. Replace if necessary after testing.
	Auto Choke— Check and adjust if necessary settings. Check and adjust if necessary fast idle speed on choke cam. Check choke for free operation.
	Check air pre-heat control damper assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
	Check and adjust if necessary engine idle speed.
*	Check timing belt condition.
	Serviceable PCV Valves — Dismantle, clean and reassemble. Disposable PCV Valves — Test and replace if necessary.
	Replace fuel filter.
	Drain and refill cooling system. Add specified quantity of anti-freeze. Clean radiator core — check for blockages.
*	Inspect condenser to ensure that it is not clogged with leaves or other foreign material. Check evaporator drain tube for dirt or other restrictions.
*	Inspect flexible hose lines for leaks and brittleness.
	Under Vehicle Operations
	Change engine oil filter.
	Check transmission oil level.
	Check rear axle oil level.
	Inspect and lubricate front suspension and steering joints.
	Inspect steering gear, linkage and dust covers for wear and security. Notify owner of any deficiencies, including loss of steering preload, for immediate rectification.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Check parking brake operation and lubricate system. Adjust if necessary.
*	Inspect flexible hose lines for leaks and brittleness.

B Service

	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage — brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings.
	Check and adjust clutch fork operating rod free travel.
	Check operation of transmission shift linkage. Adjust if necessary.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
	Inspect rear brake linings and drums for wear. Wipe off dust. Check self-adjusting mechanism and parking brake adjustment.
	Inspect front wheel bearings and check adjustment. Repack only if necessary.
	Check steering box and adjust if necessary.

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.

	Exterior Vehicle Operations
	Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear door locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

Additional Service—refer page 111.

66 Months or 110,000 km

Dealer .....

Date .....

Odometer .....

Signed .....

A SERVICE

66 Months — 110,000 Kilometre Service

	Under Hood Operations
	Change engine oil. (Every 5000 km)
	Check all fluid levels accessible in engine compartment, e.g. brake, coolant, washer, battery electrolyte, clutch.
	Inspect condition and adjust tension of all engine drive belts. Adjust if necessary using gauge.
	Inspect condition and attachment of all hoses in engine compartment, including all emission systems pipes and connections.
	Wipe inside of distributor cap.
	Check operation of exhaust heat manifold valve for free operation.
	Inspect engine air cleaner element for restriction and condition. Replace if necessary after testing.
	Check air pre-heat control damper assembly for correct cold and hot operation.
	Check operation and setting of idle stop solenoid.
	Check automatic choke for free operation.
	Check torque of carburettor mounting bolts. Check operation of EGR valve, where fitted.
	Clean radiator core — check for blockages.
	Drain and refill cooling system and recharge with anti-freeze.

	Under Vehicle Operations
	Change engine oil filter.
	Check transmission oil level.
	Check rear axle oil level.
	Inspect and lubricate front suspension and steering joints.
	Lubricate accelerator, transmission shift and clutch linkages as applicable.
	Check parking brake operation and lubricate system. Adjust if necessary.
	Inspect exhaust system and adjacent body areas for open seams or damage. Inspect for leaks and damage — brake and fuel lines, shock absorbers and mountings.
	Inspect engine and transmission mountings.
	Check and adjust clutch fork operating rod free travel.
	Inspect tyres for irregular wear or damage and advise owner, if necessary, of any corrective maintenance required. Check inflation pressures and torque wheel nuts.
	Inspect disc brake pads for wear.
*	Check refrigerant charge at sight glass.

P.T.O.

	Interior Vehicle Operations
	Check operation of all warning indicators, ignition steering lock, brake and park brake lights and interior electrical system items and controls. Check all internal lights.
	Check heating, ventilation and demisting system ducts are clear and operation is satisfactory and controls correctly adjusted.
	Seat belt inspection. Examine webbing condition, buckle operation and retractor mechanism function. Notify owner of any deficiencies observed for immediate rectification.
*	Inspect refrigerant hose connections for evidence of leaks, correct if necessary.
*	Check operations of blowers.

	Exterior Vehicle Operations
	Lubricate door handle pivots, door hinges, striker bolts or plates, hood catch and side and rear door locks.
	Check vehicle on the road for even braking and steering, transmission operation, engine response and handbrake operation. Check mirrors and seat adjustment.

Additional Service—refer page 111.

Suggested Labour Times

For Work Performed during Maintenance Services

"A" SERVICE — BASIC SERVICE TIME — 1.6 HR.

"B" SERVICE — BASIC SERVICE TIME — 2.5 HR.

"C" SERVICE — BASIC SERVICE TIME — 3.8 HR.

THE OWNER WILL BE CHARGED FOR LUBRICATIONS AND MATERIALS USED PLUS LABOUR.
AT THE TIMES RECOMMENDED ABOVE.

*** ADDITIONS TO BASIC SERVICE**

ADDITIONAL TIME AND MATERIAL REQUIRED FOR SERVICING OPTIONAL EQUIPMENT OTHER THAN THAT FITTED TO A BASIC VEHICLE AND REPAIRING OR REPLACING ANY PART FOUND FAULTY DURING THE SERVICE CHECK AND INSPECTION, WILL BE ADDED TO THE SUGGESTED LABOUR TIME AND CHARGES.

WHERE ANY DEFICIENCIES ARE NOTED SUCH ITEMS SHOULD BE REPORTED TO THE OWNER/OPERATOR SO THAT THE EXTRA WORK REQUIRED CAN BE AUTHORISED.

*** ADDITIONAL SERVICES & TIMES WHERE APPLICABLE:**

FIRST "A" SERVICE	0.2 HR.
FRONT WHEEL BEARING REPACK	
— "B" SERVICE	0.5 HR.
— "C" SERVICE	0.6 HR.
REPLACE TIMING BELT	2.5 HR

Index

A

Accelerator Pedal 30
Air Cleaner 75
Air Conditioning 5, 32-33
Anti-Freeze Fluid 73
Anti-Theft Ignition Steering Lock 19

B

Back-Up Lamp
—Operation 24
—Replacement and Specification 64
Battery 75
Bulb
—Replacement and Specification 63
Brake
—Operation 30
—Fuel Level Indicator Light 29
—Parking 30
—Master Cylinder 74

C

Capacities 59-60
Cassette Player 31
Carbon Monoxide Warning 17
Chassis Number 59
Child's Seat Belts 11
Clearances of Settings 60-61
Clutch Pedal 30
Combination Switches 21
Controls
—Steering Column 19
—Transmission 24
—Floor 30
—Instrument Panel 18, 26
—Ventilation 32
Cooling System
—Radiator Pressure Cap 73
—Checking Coolant Levels 73
—Filling the Cooling System 73
—Draining and Flushing 73
—Corrosion Inhibitor 73
—Anti-Freeze 73
—Capacity 60
Customer Assistance 47

D

Dealer List 47-57
Demister 32
Dimension (Vehicle) 60
Dipping (Headlamp) 21
Dome Lamp 35
—Replacement and Specification 62-63
Door
—Locks 7, 8

E

Emission Control Systems 45, 46
Emergency Conditions
—Emergency Starting 40-41
—Spare Wheel Storage 37
—Indicator Lights 43-44
—Wheel Changing 38
—Overheating 43
—Towing a Disabled Vehicle 42
Emergency Starting
—Push Starting 41
—Jump Starting 40
Engine
—Data 60
—Compartment Cover 14
—Fuel Requirements 68
—Initial Oil Fill 66
—Maintaining Oil Level 66
—Oil Consumption 67
—Oil Filter Replacement 68
—Oil Change Intervals 69
—Oil Viscosity Grades 70
—Number 59
Evaporative Control System 76
Exhaust Gas
—Carbon Monoxide Warning 17

F

Floor Controls
—Accelerator Pedal 30
—Brake Operation 30
—Clutch Pedal 30
—Parking Brake 30
Fuel
—Gauge 27
—Requirements 68
—Economy 5
—Tank Capacity 60
Fumes 17
Fuse System 63
Fusible Link 64

G

Generator Indicator Light 29
Getting to know your Shuttle 3
—Safe Driving 6
—Keys and Locks 7, 8
—Rear Vision Mirrors 14
—Running In 4
—Seat Adjustment 15
—Seat Belts 9-12
—Maintenance 83-110

H

Hazard Warning Flashers 23, 37
Heater System 32
Headlamp
—Dipping 21
—Replacement and Specifications 62, 63
High Beam Indicator Light 28, 29
Horns 19

I

Identification Certificate Front Cover
Ignition Steering Lock 19
Indicator Lights 26
Indicator Lights Panel 28
Indicator Lights 43-44
Instruments
—Bulb Replacement and Specification 62-63
Instrument Lights 28
—Light Switch 21
—Headlamp Dipping 21
—Windshield Wipers and Washers 22, 23

J

Jack 38
Jump Starting 40

K

Keys and Locks 7, 8

L

Lamps
—Turn Signal 28, 29
—Headlamp High Beam 21
—Light Switch 21
—Bulb Replacement and Specification 62-63
Lane Change Indication 21
Light
—Indicator 21
—Switch 21
Loading Information 60
Locks (and Keys)
—Keys 7
—Door Lock Operation 7
—Fuel Filler Locking Cap 8
—Anti-Theft Ignition Steering Lock 19
Lubricants and Filters 72
Lubrication Chart 70

M

Maintenance Certificates 87-110
Maintenance Plan 83-85
Manual Transmission 24

Meters and Indicator Lights 26
Mirrors (Rear Vision) 14

O

Odometer 26
Oil
—Initial Oil Fill etc. 66
—Pressure Indicator Light 28
—Maintenance Level 66
—Consumption 67
—Filter Replacement 68
—Change Intervals 69
—Viscosity Grades 70
—Transmission Oils 70
Overheating 43
Owner's Responsibility 81

P

Parking Brake 30
Parking Brake Indicator Light 34
Parking Lamp
—Replacement and Specification 64, 65
Push Starting 40

R

Radio 31
Radiator
—Overheating 43
—Surge Tank 43
Rear Vision Mirrors 14
Running In 4

S

Safe Driving Hints 6
Safety Check List 3
Seat Adjustment 15
Seat Belts 9-12
—General 10
Serial Numbers 59
Service and Maintenance 83-110
Spark Plug Gap 60
Spare Wheel Storage 37
Specifications 59-61
—Vehicle Dimension 60
—Vehicle Identification Number 59
—Engine Data 60
—Fuse System 63
—Headlamp and Bulb 63
—Tyre Pressures 61, 77
Speedometer 27
Starting and Driving 34-35
Starting and Operating 17
—Exhaust Gas Warning 17
—Steering Column Controls 19
—Floor Controls 30
—Instrument Panel 26
—Instrument Dials 26
—Indicator Lights 28
—Ventilation Systems 32
Steering Column Controls 19
—Ignition Lock 19
—Windshield Wipers/Washers 22
—Turn Signal Operation 21
—Headlamp Dipping 21
—Hazard Warning 23
Stop/Tail Lamp
—Replacement and Specification 62-63

T

Tape Deck 31
Temperature
—Gauge 27
Towing a Disabled Vehicle 42
Transmission Controls 24
Turn Signal
—Operation 21
—Indicator Light 28
Turn Signal Lamp
—Replacement and Specification 62-63
Tyres 77-79
—Pressures 61, 77

V

Valve Clearances 60-61
Vehicle Identification
Certificate Front Cover
Vehicle
—Identification Number 59
—Dimensions 60
—Weight 60
Ventilation Systems
—Ventilators 32
—Heater/Demister 32

W

Warning Light
—Brake 29
—Generator 28
—Oil Pressure 28
—Hazard Warning 23, 37
Weight Vehicle 60
Wheel Changing 38
—Jack 38
Windshield
—Defogging 32
—Wipers and Washers 22, 76
—Cleanliness 76
—Wiper Blades (Cleaning) 76
—Washer Tank 23
—Back Door Washer Wiper 25

ACCIDENTS

All motorists are advised to learn what to do at the scene of an accident, particularly where persons are injured. Injured people can choke to death if their air passages are not cleared. They can bleed to death unless the bleeding is stopped. They may require mouth-to-mouth resuscitation, may have to be moved, even though badly injured. It is important that you understand how to avoid further damaging an injured neck or back or other broken limbs.

The following notes may help.

- **Part 1. Accident—being involved.**
- **Part 2. Accident—being a witness.**
- **Part 3. Medical assistance.**

Part 1. Accident—being involved

If you are involved in an accident you are advised to do as follows:

Stop immediately.

Remember that time is vital. Remain calm and alert. Think quickly and clearly.

Give all possible assistance to all injured persons. (See Part 3 Medical Assistance.)

Send for police and ambulance if anyone has been injured. Send information as accurately as possible. Give the exact location, the number of injured people and a brief report on the overall situation.

Perhaps take charge of the situation.

Warn all other traffic approaching the scene. Turn off ignition switches. Stop any smoking near spilt petrol. In darkness, try and light up the area to warn others.

Clear the road of accident debris.

Exchange your name, address, vehicle registration number and the vehicle owner's name and address with the other parties involved in the accident.

If damage to property only has occurred, report the facts to the owner of the damaged property or to his or her representative; to any police present at the scene or to the nearest Police Station.

Try and note all important facts because such details may be important if needed later.

Part 2. Accident—being a witness

If you witness a road accident or it becomes your task to stop and help at the scene of an accident, do this:

Keep in mind that an observant witness can prove most helpful. Some day you yourself might be very glad of help from a witness.

DO NOT stop at the scene of an accident *just to be a spectator.*

Where other people are already in attendance and giving assistance, **you should stop only if you can contribute assistance.**

Give what assistance you can to any injured persons. (See Part 3 Medical Assistance.)

Follow most of the steps suggested in Part 1. Perhaps you may have to take charge of the accident situation.

Part 3. Medical Assistance

Keep calm and think clearly.

Your experience may not be much but do your best. Don't just stand by and let an injured person die.

- Look after the unconscious person first. Check for breathing. If no breathing, then check if air passages

are clear, i.e. nose and mouth. Use your fingers to clear air passages if necessary. If the air way is clear then mouth-to-mouth resuscitation may be needed at once.

Unconscious people can choke.
Carefully turn to one side.
Tilt the head back slightly.
Wipe out the mouth with your finger to remove blood, vomit, broken teeth or dentures.

- You must be most careful in moving an injured person. Often it is best not to move at all but, in conditions of danger, that is not always possible. Serious and permanent damage can be done to an injured neck or back if not supported during movement. NEVER BEND A NECK OR BACK. KEEP THEM STRAIGHT. All injured limbs require support when an injured person has to be moved.
- Provided it is not dangerous to do so because of other injuries, an unconscious person will do best in the "coma position" illustrated here.

Lay the person on one side and—if it will not aggravate any injuries—then: Bend the uppermost knee until the thigh is at right angle to body.
Bend the uppermost arm and elbow so that the hand lies near the face.
Gently pull the underneath arm so that it rests straight on the ground free of any body weight.

- Try to stop bleeding by applying direct pressure, using your hands, or by pressing torn flesh together. Use any clean cloth available. Fold cloths to make pads. If necessary, press one pad on top of another. Keep pressure around edges of a wound BUT NEVER USE A TOURNIQUET.

Shock may be treated by reassurance, relieving pain, controlling any bleeding and keeping the injured person warm *but not hot.* Best not to give any fluids and NEVER ALCOHOL.

- If the injured person is in danger and has to be moved, try and have three or four people help and concentrate on not bending the neck, spine and injured limbs. **Keeping the neck and spine straight is most important.**

Illustrations reproduced from "The Victorian Road Code" with permission from Road Safety and Traffic Authority of Victoria.

COPYRIGHT
GENERAL MOTORS-HOLDEN'S SALES PTY. LTD.
(Inc. in Vic.)
(Reproduction in whole or part is prohibited without written approval)

Printed in Australia by The Dominion Press-Hedges & Bell, Maryborough, 3465.